

# ISO 22476-6:2018 (E)

## Geotechnical investigation and testing — Field testing — Part 6: Self-boring pressuremeter test

---

### Contents

	Foreword
1	Scope
2	Normative references
3	Terms and definitions
4	Symbols
5	Equipment
5.1	General
5.2	Self-boring pressuremeter probe
5.3	Self-boring head
5.4	Pressure and displacement CU
5.5	The connecting lines
5.6	The injected fluid
5.7	Means of measurement and control
5.7.1	Data acquisition
5.7.2	Display of readings
6	Test procedure
6.1	Selection of equipment and procedures
6.2	Calibration of the testing device and corrections of readings
6.3	Probe placing
6.4	Relaxation
6.5	Loading program
6.5.1	General
6.5.2	End of test
6.6	Backfilling of the borehole
7	Test results — Interpretation of tests
8	Self-boring pressuremeter test report
Annex A	(normative) Calibration and corrections
A.1	Measuring devices
A.2	Stiffness of cell membranes
A.2.1	Preparation of the self-boring pressuremeter for a membrane pressure loss test
A.2.2	Membrane stiffness correction test
A.3	Membrane compression
A.3.1	The calibration cylinder
A.3.2	Membrane compression test
A.4	Estimate of readings corrections
Annex B	(informative) Placing the pressuremeter probe in the ground
B.1	General
B.2	Selecting self-boring tool
Annex C	(normative) Accuracy
C.1	Accuracy of the measuring devices
Annex D	(informative) Strain conversions