

# ISO/TR 23672:2026-03 (E)

## Ergonomics of the thermal environment: Adaptive methods for achieving thermal comfort

---

### Contents

Page

Foreword.....	iv
Introduction.....	v
<b>1</b> <b>Scope</b> .....	<b>1</b>
<b>2</b> <b>Normative references</b> .....	<b>1</b>
<b>3</b> <b>Terms and definitions</b> .....	<b>1</b>
<b>4</b> <b>Approaches to adaptive thermal comfort models</b> .....	<b>3</b>
<b>5</b> <b>Regression based adaptive comfort models</b> .....	<b>3</b>
5.1    Background and model formulation.....	3
5.2    Model development.....	4
5.3    Values for model coefficients.....	4
5.4    Model application in national and international standards.....	4
<b>6</b> <b>Adaptive PMV (aPMV) model</b> .....	<b>5</b>
6.1    General.....	5
6.2    Background and model formulation.....	5
6.3    Model development.....	7
6.4    Values for model coefficients.....	8
6.5    Model application in national and international standards.....	8
<b>7</b> <b>The adaptive thermal heat balance (ATHB) model</b> .....	<b>8</b>
7.1    General.....	8
7.2    Background and model formulation.....	8
7.3    Model development.....	9
7.4    Values for model coefficients.....	9
7.5    Model application in national and international standards.....	9
<b>Annex A (informative) Derivation and recommendations of adaptive coefficients for aPMV</b> .....	<b>10</b>
<b>Annex B (informative) Derivation of equations and coefficients for ATHB<sub>PMV</sub></b> .....	<b>12</b>
<b>Bibliography</b> .....	<b>15</b>