

# DIN EN 17278:2022-01 (E)

## Natural gas vehicles - Vehicle fuelling appliances

---

<b>Contents</b>		<b>Page</b>
European foreword .....		4
<b>1</b>	<b>Scope .....</b>	<b>5</b>
<b>2</b>	<b>Normative references .....</b>	<b>5</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>7</b>
<b>4</b>	<b>Abbreviations .....</b>	<b>10</b>
<b>5</b>	<b>Risk management .....</b>	<b>10</b>
<b>6</b>	<b>General principles of design .....</b>	<b>11</b>
6.1	General construction .....	11
6.2	General requirements .....	11
6.3	Materials .....	12
6.4	Internal systems and components of VFA .....	12
6.4.1	Fuel delivery system .....	12
6.4.2	Fuelling pressure discharge system .....	14
6.4.3	Locking system .....	14
6.4.4	Compressor .....	14
6.4.5	Gas containment system .....	14
6.4.6	Temperature compensation system .....	15
6.4.7	Dryer .....	16
6.4.8	Safety means .....	16
6.4.9	Pipework .....	17
6.5	Permanent joining .....	17
6.6	Connection to the distribution gas network .....	17
6.7	Gas composition and odorization .....	18
6.8	Noise attenuation .....	18
6.9	Ventilation .....	18
<b>7</b>	<b>Enclosure .....</b>	<b>18</b>
<b>8</b>	<b>Testing .....</b>	<b>19</b>
8.1	General .....	19
8.2	Strength pressure (proof) test .....	19
8.2.1	General .....	19
8.2.2	Procedure of strength pressure (proof) test .....	19
8.2.3	Fatigue test .....	20
8.3	Leak testing .....	20
8.3.1	General .....	20
8.3.2	Procedure for gas leakage test .....	20
8.3.3	Liquid leakage testing .....	20
8.4	Checking of safety devices .....	20
8.5	Periodic inspection .....	21
8.5.1	General .....	21
8.5.2	Periodic inspection of cylinders .....	21
8.5.3	Periodic inspection of fuelling hose .....	21
<b>9</b>	<b>Installation .....</b>	<b>21</b>
9.1	General .....	21

9.2	VFA location .....	21
9.3	VFA installation outdoors .....	23
9.3.1	VFA location outdoors .....	23
9.3.2	Installation conditions .....	23
9.3.3	Ventilation conditions .....	23
9.4	VFA installation indoors .....	23
9.4.1	VFA location indoors .....	23
9.4.2	Installation conditions .....	24
9.4.3	Ventilation conditions .....	24
9.4.4	Compatibility with other gas appliances .....	25
9.5	Commissioning .....	25
10	Operation .....	25
10.1	General .....	25
10.2	Installation and servicing manual .....	25
10.2.1	General .....	25
10.2.2	Installation instructions .....	26
10.2.3	Maintenance instructions .....	27
10.2.4	Removal instructions for VFA .....	28
10.2.5	Servicing and inspection instructions .....	28
10.3	User's manual .....	28
10.3.1	General .....	28
10.3.2	Front cover .....	28
10.3.3	Safety section .....	29
10.3.4	Additional safety information .....	29
11	User of VFA .....	30
12	Marking and labelling .....	31
13	Maintenance and testing frequency of gas detection system .....	31
<b>Annex A (informative) Additional safety precautions for indoor fuelling of NGV by means of VFA installed outdoors .....</b>		<b>32</b>
<b>Annex ZA (informative) Relationship between this European Standard and the Essential requirements of EU Directive 2014/68/EU (Pressure equipment Directive) aimed to be covered .....</b>		<b>33</b>
<b>Bibliography .....</b>		<b>34</b>