DIN EN 12159:2013-03 (E)

Builders hoists for persons and materials with vertically guided cages

Contents

Page

Foreword 4

Introduction 5

1 Scope 6

2 Normative references 7

3 Terms and definitions 8

4 List of hazards 10

5 Safety requirements and/or measures 13
5.1 General 13
5.2 Load combinations and calculations 14
5.2.3 Safety factors 19
5.2.4 Load cases, the different combinations of loads and forces which are to be calculated 20
5.2.5 Stability 21
5.2.6 Fatigue stress analysis of drive and braking system components 21
5.3 Base frame 22
5.4 Mast, ties and buffers 22
5.4.1 Guide structures and masts 22
5.4.2 Mast ties 22
5.4.3 Buffers 23
5.5 Hoistway protection and landing access 23
5.5.1 General 23
5.5.2 Hoist base enclosure 23
5.5.3 Landing access 23
5.5.4 Materials for enclosure and guarding 27
5.5.5 Landing gate locking devices 28
5.5.6 Clearances 29
5.6 Cage 29
5.6.1 General requirements 29
5.6.2 Safety devices against falling of the cage 31
5.6.3 Overload detection device 32
5.7 Drive unit 33
5.7.1 General provisions 33
5.7.2 Protection and accessibility 33
5.7.3 Suspension system 34
5.7.4 Braking system 39
5.7.5 Counterweight 40
5.8 Electric installations and appliances 40
5.8.1 General 40
5.8.2 Protection against electric faults 41
5.8.3 Protection against the effects of external influences 41
5.8.4 Electric wiring 41
5.8.5 Contactors, relay-contactors 42
5.8.6 Electric safety devices 42
5.8.7 Safety contacts 42
5.8.8 Lighting 42
5.9 Control and limiting devices 43
5.9.1 General 43

5.9.2 Travel limit switches 43
5.9.3 Slack rope device 43
5.9.4 Erection accessories 43
5.9.5 Stopping devices 43
5.9.6 Stopping the machine 44
5.9.7 Control modes 44
5.10 Breakdown conditions 45
5.10.1 Alarm device 45
5.10.2 Emergency escape 45
5.10.3 Manual lowering by persons trapped in the cage 45
5.10.4 Emergency operation by a competent person 45
5.11 Noise 46
5.11.1 General 46
5.11.2 Noise reduction at the design stage 46
5.11.3 Noise emission measurement 46

6 Verification 46
6.1 Verification of design 46
6.2 Special verification tests 49
6.2.1 Introduction 49
6.2.2 Locking devices for cage and landing gates 50
6.2.3 Overspeed safety device and overspeed governors 52
6.2.4 Energy accumulation type buffers with buffered return movement and energy dissipation buffers 53
6.3 Verification tests on each machine before first use 53

7 User information 53
7.1 Instruction handbook 53
7.1.1 Comprehensive information 53
7.1.2 Contents of the instruction handbook 54
7.2 Markings 59
7.2.1 General 59
7.2.2 Rating plate 59
7.2.3 Mast or guide section identification label 59
7.2.4 Basic user information label 59
7.2.5 Label in the cage 60
7.2.6 Label at ground level 60
7.2.7 Label at overspeed device 60
7.2.8 Drive motor label 60
7.3 Marking of control elements 60

Annex A (normative) European stormwind map 61

Annex B (normative) Electric safety devices 62

Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EC 63

Bibliography 64