

DIN EN ISO 8437-2:2023-11 (E)

Snow throwers - Safety requirements and test procedures - Part 2: Pedestrian-controlled snow throwers (ISO 8437-2:2019)

| Contents | Page |
|--|-------------|
| European foreword | 3 |
| Foreword | 4 |
| Introduction | 5 |
| 1 Scope | 6 |
| 2 Normative references | 6 |
| 3 Terms and definitions | 7 |
| 4 Requirements for pedestrian-controlled snow thrower safety | 7 |
| 4.1 General..... | 7 |
| 4.2 Controls..... | 7 |
| 4.2.1 General..... | 7 |
| 4.2.2 Engine stopping and starting..... | 10 |
| 4.2.3 Collector and impeller control..... | 11 |
| 4.2.4 Self-propelled pedestrian-controlled snow throwers..... | 12 |
| 4.3 Guards, shields, chutes, deflectors and housings..... | 12 |
| 4.3.1 General..... | 12 |
| 4.3.2 Hot surfaces..... | 15 |
| 4.3.3 Engine exhaust..... | 15 |
| 4.3.4 Snow clean-out tool..... | 15 |
| 4.4 Fuel..... | 16 |
| 4.4.1 Fuel tank overfill test..... | 16 |
| 4.4.2 Fuel line axial pull test..... | 16 |
| 4.5 Electrical equipment: battery powered circuits (not including magneto grounding circuits)..... | 16 |
| 4.5.1 Insulated cables..... | 16 |
| 4.5.2 Battery installation..... | 16 |
| 4.5.3 Overload protection..... | 16 |
| 4.5.4 Terminals and non-insulated electrical parts..... | 16 |
| 4.6 Power drives..... | 16 |
| 4.7 Probe test..... | 17 |
| 4.7.1 Test procedure..... | 17 |
| 4.7.2 Test acceptance..... | 17 |
| 4.8 Electromagnetic immunity..... | 18 |
| 4.9 Noise..... | 18 |
| 4.10 Vibration..... | 18 |
| 5 Instructions for use | 18 |
| 5.1 Instruction handbook..... | 18 |
| 5.2 Markings..... | 18 |
| 5.3 Warnings..... | 18 |
| Annex A (normative) Instruction handbook | 19 |
| Bibliography | 22 |