

# DIN EN ISO 19014-3:2019-06 (E)

## Earth-moving machinery - Functional safety - Part 3: Environmental performance and test requirements of electronic and electrical components used in safety-related parts of the control system (ISO 19014-3:2018)

---

| <b>Contents</b>                |   | <b>Page</b> |
|--------------------------------|---|-------------|
| <b>European foreword</b> ..... |   | <b>4</b>    |
| <b>Foreword</b> .....          |   | <b>5</b>    |
| <b>Introduction</b> .....      |   | <b>6</b>    |
| <b>1</b>                       | <b>Scope</b> .....  | <b>7</b>    |
| <b>2</b>                       | <b>Normative references</b> .....                             | <b>7</b>    |
| <b>3</b>                       | <b>Terms and definitions</b> .....                            | <b>8</b>    |
| <b>4</b>                       | <b>Functional status classifications</b> .....                | <b>8</b>    |
| 4.1                            | Class A.....  | 8           |
| 4.2                            | Class B.....  | 8           |
| 4.3                            | Class C.....  | 8           |
| 4.4                            | Class D.....  | 8           |
| <b>5</b>                       | <b>Tests and requirements</b> .....                           | <b>8</b>    |
| 5.1                            | General.....  | 8           |
| 5.2                            | Dust.....   | 9           |
|                                | 5.2.1 Purpose.....  | 9           |
|                                | 5.2.2 Test method.....  | 9           |
| 5.3                            | Chemical resistance.....                                      | 9           |
|                                | 5.3.1 Purpose.....  | 9           |
|                                | 5.3.2 Test method.....  | 9           |
| 5.4                            | Salt spray.....   | 10          |
|                                | 5.4.1 Purpose.....  | 10          |
|                                | 5.4.2 Test method.....  | 10          |
| 5.5                            | Pressure wash.....  | 10          |
|                                | 5.5.1 Purpose.....  | 10          |
|                                | 5.5.2 Test method.....  | 10          |
| 5.6                            | Random vibration.....   | 10          |
|                                | 5.6.1 Purpose.....  | 10          |
|                                | 5.6.2 Test method.....  | 10          |
| 5.7                            | Operating shock.....  | 11          |
|                                | 5.7.1 Purpose.....  | 11          |
|                                | 5.7.2 Test method.....  | 11          |
| 5.8                            | Temperature cycles.....                                       | 12          |
|                                | 5.8.1 Purpose.....  | 12          |
|                                | 5.8.2 Test method.....  | 12          |
| 5.9                            | Thermal shock.....  | 13          |
|                                | 5.9.1 Purpose.....  | 13          |
|                                | 5.9.2 Test method.....  | 13          |
| 5.10                           | Humidity cycles.....  | 14          |
|                                | 5.10.1 Purpose.....   | 14          |
|                                | 5.10.2 Test method.....                                       | 14          |
| 5.11                           | Overvoltage condition.....                                    | 14          |
|                                | 5.11.1 Purpose.....   | 14          |
|                                | 5.11.2 Test method.....                                       | 14          |
| 5.12                           | Undervoltage condition (reset behaviour at voltage drop)..... | 14          |
|                                | 5.12.1 Purpose.....   | 14          |
|                                | 5.12.2 Test method.....                                       | 14          |

|  |                                    |           |
|--|------------------------------------|-----------|
| 5.13   | Electromagnetic compatibility..... | 14        |
| 5.13.1   | Purpose.....                       | 14        |
| 5.13.2   | Test method.....                   | 15        |
| 5.14   | Reverse polarity.....              | 15        |
| 5.14.1   | Purpose.....                       | 15        |
| 5.14.2   | Test method.....                   | 15        |
| <b>Annex A (informative) Test checklist.....</b> |                                    | <b>16</b> |
| <b>Bibliography.....</b>                         |                                    | <b>17</b> |