

# ISO/TS 17165-2:2018-04 (E)

## Hydraulic fluid power - Hose assemblies - Part 2: Practices for hydraulic hose assemblies

---

<b>Contents</b>		<b>Page</b>
Foreword .....		v
Introduction .....		vi
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Safety considerations .....</b>	<b>2</b>
4.1	General .....	2
4.2	Fluid injections .....	2
4.3	Whipping hoses .....	2
4.4	Burns from conveyed fluids .....	2
4.5	Fire and explosions from conveyed fluids .....	2
4.6	Fire and explosions from static-electric discharge .....	2
4.7	Electrical shock .....	3
4.8	Mechanisms controlled by fluid power .....	3
<b>5</b>	<b>Hose selection and routing .....</b>	<b>3</b>
5.1	General .....	3
5.2	System pressures .....	3
5.3	Suction .....	3
5.4	External pressure .....	3
5.5	Temperature .....	3
5.6	Permeation .....	4
5.7	Compatibility between hose materials and system fluids .....	4
5.8	Environment .....	4
5.9	Static-electric discharge .....	5
5.10	Sizing .....	5
5.11	Unintended uses .....	5
5.12	Specifications and standards .....	5
5.13	Unusual applications .....	5
5.14	Hose assembly cleanliness .....	5
5.15	Hose fittings .....	5
5.16	Vibration .....	5
5.17	Hose cover protection .....	5
5.18	External physical abuse .....	6
5.19	Swivel hose fittings and connectors .....	6
5.20	Rotary connectors .....	6
5.21	Slings and clamps .....	6
5.22	Minimum bend radius .....	7
5.23	Elbows and connectors .....	7
5.24	Lengths .....	7
5.24.1	General .....	7
5.24.2	Motion absorption .....	8
5.24.3	Tolerances and machine motion .....	8
5.24.4	Change in hose length due to changes in pressure .....	8
5.25	Hose movement and bending .....	9

<b>6</b>	<b>Hose assembly fabrication .....</b>	<b>10</b>
<b>6.1</b>	<b>General .....</b>	<b>10</b>
<b>6.2</b>	<b>Component inspection .....</b>	<b>10</b>
<b>6.3</b>	<b>Hose fitting parts .....</b>	<b>11</b>
<b>6.4</b>	<b>Compatibility between hose and hose fittings .....</b>	<b>11</b>
<b>6.5</b>	<b>Hose assembly equipment .....</b>	<b>11</b>
<b>6.6</b>	<b>Safety equipment .....</b>	<b>11</b>
<b>6.7</b>	<b>Condition of hose assembly parts .....</b>	<b>11</b>
<b>6.8</b>	<b>Cleanliness of hoses and hose assemblies .....</b>	<b>11</b>
<b>6.9</b>	<b>Temperature .....</b>	<b>11</b>
<b>6.10</b>	<b>Assembly inspection .....</b>	<b>11</b>
<b>6.11</b>	<b>Marking .....</b>	<b>12</b>
<b>7</b>	<b>Hose installation and replacement .....</b>	<b>12</b>
<b>7.1</b>	<b>General .....</b>	<b>12</b>
<b>7.2</b>	<b>Pre-installation inspection .....</b>	<b>12</b>
<b>7.3</b>	<b>Handling during installation .....</b>	<b>12</b>
<b>7.4</b>	<b>Twist angle and orientation .....</b>	<b>12</b>
<b>7.5</b>	<b>Securing and protection .....</b>	<b>13</b>
<b>7.6</b>	<b>Routing .....</b>	<b>13</b>
<b>7.7</b>	<b>Assembly torque .....</b>	<b>13</b>
<b>7.8</b>	<b>System checkouts .....</b>	<b>13</b>
<b>8</b>	<b>Maintenance inspection .....</b>	<b>13</b>
<b>8.1</b>	<b>General .....</b>	<b>13</b>
<b>8.2</b>	<b>Inspection frequency .....</b>	<b>13</b>
<b>8.3</b>	<b>Visual inspection (hose and hose fittings) .....</b>	<b>13</b>
<b>8.4</b>	<b>Visual inspection (all other components in the system) .....</b>	<b>14</b>
<b>8.5</b>	<b>Functional tests .....</b>	<b>15</b>
<b>9</b>	<b>Storage .....</b>	<b>15</b>
<b>9.1</b>	<b>General .....</b>	<b>15</b>
<b>9.2</b>	<b>Age control .....</b>	<b>15</b>
<b>9.2.1</b>	<b>Shelf life .....</b>	<b>15</b>
<b>9.2.2</b>	<b>Storage period .....</b>	<b>15</b>
<b>9.3</b>	<b>Storage conditions .....</b>	<b>15</b>
<b>10</b>	<b>Identification statement (reference to this document) .....</b>	<b>17</b>
	<b>Annex A (informative) Examples of actual failure resulting from improper use .....</b>	<b>18</b>
	<b>Bibliography .....</b>	<b>20</b>