

# ISO/TS 17165-2:2018-04 (E)

## Hydraulic fluid power - Hose assemblies - Part 2: Practices for hydraulic hose assemblies

---

<b>Contents</b>		<b>Page</b>
Foreword .....		v
Introduction .....		vi
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Safety considerations .....</b>	<b>2</b>
4.1	General .....	2
4.2	Fluid injections .....	2
4.3	Whipping hoses .....	2
4.4	Burns from conveyed fluids .....	2
4.5	Fire and explosions from conveyed fluids .....	2
4.6	Fire and explosions from static-electric discharge .....	2
4.7	Electrical shock .....	3
4.8	Mechanisms controlled by fluid power .....	3
<b>5</b>	<b>Hose selection and routing .....</b>	<b>3</b>
5.1	General .....	3
5.2	System pressures .....	3
5.3	Suction .....	3
5.4	External pressure .....	3
5.5	Temperature .....	3
5.6	Permeation .....	4
5.7	Compatibility between hose materials and system fluids .....	4
5.8	Environment .....	4
5.9	Static-electric discharge .....	5
5.10	Sizing .....	5
5.11	Unintended uses .....	5
5.12	Specifications and standards .....	5
5.13	Unusual applications .....	5
5.14	Hose assembly cleanliness .....	5
5.15	Hose fittings .....	5
5.16	Vibration .....	5
5.17	Hose cover protection .....	5
5.18	External physical abuse .....	6
5.19	Swivel hose fittings and connectors .....	6
5.20	Rotary connectors .....	6
5.21	Slings and clamps .....	6
5.22	Minimum bend radius .....	7
5.23	Elbows and connectors .....	7
5.24	Lengths .....	7
5.24.1	General .....	7
5.24.2	Motion absorption .....	8
5.24.3	Tolerances and machine motion .....	8
5.24.4	Change in hose length due to changes in pressure .....	8
5.25	Hose movement and bending .....	9

<b>6</b>	<b>Hose assembly fabrication .....</b>	<b>10</b>
6.1	General .....	10
6.2	Component inspection .....	10
6.3	Hose fitting parts .....	11
6.4	Compatibility between hose and hose fittings .....	11
6.5	Hose assembly equipment .....	11
6.6	Safety equipment .....	11
6.7	Condition of hose assembly parts .....	11
<b>6.8</b>	<b>Cleanliness of hoses and hose assemblies .....</b>	<b>11</b>
6.9	Temperature .....	11
6.10	Assembly inspection .....	11
6.11	Marking .....	12
<b>7</b>	<b>Hose installation and replacement .....</b>	<b>12</b>
7.1	General .....	12
7.2	Pre-installation inspection .....	12
7.3	Handling during installation .....	12
7.4	Twist angle and orientation .....	12
7.5	Securing and protection .....	13
7.6	Routing .....	13
7.7	Assembly torque .....	13
7.8	System checkouts .....	13
<b>8</b>	<b>Maintenance inspection .....</b>	<b>13</b>
8.1	General .....	13
8.2	Inspection frequency .....	13
8.3	Visual inspection (hose and hose fittings) .....	13
8.4	Visual inspection (all other components in the system) .....	14
8.5	Functional tests .....	15
<b>9</b>	<b>Storage .....</b>	<b>15</b>
9.1	General .....	15
9.2	Age control .....	15
9.2.1	Shelf life .....	15
9.2.2	Storage period .....	15
9.3	Storage conditions .....	15
<b>10</b>	<b>Identification statement (reference to this document) .....</b>	<b>17</b>
<b>Annex A (informative) Examples of actual failure resulting from improper use .....</b>		<b>18</b>
<b>Bibliography .....</b>		<b>20</b>