

ISO 20031:2020-02 (E)

Radiological protection - Monitoring and dosimetry for internal exposures due to wound contamination with radionuclides

Contents	Page
Foreword	v
Introduction	vi
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Symbols and abbreviated terms	5
4.1 Symbols	5
4.2 Abbreviated terms	5
5 Purpose and need for special monitoring programmes for internal exposures due to wound contamination with radionuclides	5
6 General aspects of wound contamination	6
6.1 Introduction	6
6.2 Category of wound contaminants	6
6.3 Types of wounds and their specific retention of radionuclides	7
7 Monitoring programmes to assess contamination via a wound	7
7.1 Introduction	7
7.2 Main steps for the monitoring and dosimetry for internal exposures due to wound contamination with radionuclides	7
7.3 Collection of information to characterize the contaminated wound	8
7.3.1 General	8
7.3.2 Information concerning the type of wound	9
7.3.3 Information concerning the radioactive contaminant	9
7.4 In vivo wound measurements	9
7.5 Systemic activity monitoring	10
8 Performance criteria for radiobioassay measurements	11
9 Procedure for local and systemic dose assessment	11
9.1 Local (wound site) dose assessment	11
9.2 Systemic dose assessment	11
9.3 Impact of medical intervention on dose assessment	13
9.3.1 Local chelation therapy and/or the excision of contaminated tissue from the wound	13
9.3.2 Decorporation therapy	13
9.4 Software tools for bioassay data interpretation	13
9.5 Uncertainties	14
9.5.1 General	14
9.5.2 Uncertainties on local dose assessment	14
9.5.3 Uncertainties on internal dose assessment	14
9.6 Quality assurance	14
10 Recording	15
10.1 Recording in vivo measurement results	15
10.2 Recording in vitro radiobioassay and treatment waste results	15

11	Documentation of the dose assessment	16
12	Reporting	16
Annex A (informative) Schematic representation of NCRP wound model, default parameters for retention equations and default transfer rates for the wound model for the various categories of radionuclides in wounds (adapted from NCRP report 156 (2007)^[3])	17	
Annex B (informative) Types of wounds and their specific retention of radionuclides	20	
Annex C (informative) Example of a summary sheet that should follow the contaminated worker during his initial care	23	
Annex D (informative) Overview of typical methods used for in vitro bioassay measurements	24	
Annex E (informative) Equivalent dose rate in a contaminated wound ($\text{mSv}\cdot\text{h}^{-1}\cdot\text{kBq}^{-1}$) and equivalent dose rate received by the skin ($\text{mSv}\cdot\text{h}^{-1}\cdot\text{kBq}^{-1}\cdot\text{cm}^2$) for selected radionuclides	25	
Annex F (informative) Committed effective dose coefficients for intake of selected radionuclides via a contaminated wound for all wound model categories (adapted from Toohey RE et al., 2014^[11])	27	
Annex G (informative) The IDEAS Guidelines^[14] provide guidelines for the estimation of committed doses from incorporation monitoring data in case of wound	30	
Bibliography	31	