ISO 5167-3:2020 (E)

Measurement of fluid flow by means of pressure differential devices inserted in circular cross-section conduits running full — Part 3: Nozzles and Venturi nozzles

Contents

	Forew	vord	
	Introd	luction	
I	Scope	9	
2	Norm	Normative references	
3	Terms	s and definitions	
1	Princi	ples of the method of measurement and computation	
5	Nozzl	Nozzles and Venturi nozzles	
	5.1	ISA 1932 nozzle	
	5.1.1	General shape	
	5.1.2	Nozzle profile	
	5.1.2 5.1.3	Downstream face	
		Material and manufacture	
	5.1.4 5.1.5		
	5.1.5 5.1.6	Pressure tappings Coefficients of ISA 1932 nozzles	
	5.1.6 5.1.6.1	Limits of use	
	5.1.6.2	Discharge coefficient, C	
	5.1.6.3	Expansibility [expansion] factor, ε	
	5.1.7	Uncertainties	
	5.1.7.1	Uncertainty of discharge coefficient, C	
	5.1.7.2	Uncertainty of expansibility [expansion] factor ε	
	5.1.8	Pressure loss, Δω	
	5.2	Long radius nozzles	
	5.2.1	General	
	5.2.2	Profile of high-ratio nozzle	
	5.2.3	Profile of low-ratio nozzle	
	5.2.4	Material and manufacture	
	5.2.5	Pressure tappings	
	5.2.6	Coefficients of long radius nozzles	
	5.2.6.1	Limits of use	
	5.2.6.2	Discharge coefficient, C	
	5.2.6.3	Expansibility [expansion] factor, ε	
	5.2.7	Uncertainties	
	5.2.7.1	Uncertainty of discharge coefficient C	
	5.2.7.2	Uncertainty of expansibility [expansion] factor ε	
	5.2.8	Pressure loss, Δω	
	5.3	Throat-tapped nozzles	
	5.3.1	General	
	5.3.2	Profile of throat-tapped nozzle	
	5.3.3	Material and manufacturing	
	5.3.4	Pressure Tappings	
	5.3.4.1	Angular position of the pressure tappings	
	5.3.4.2	Circularity and edge of pressure tappings	
	5.3.4.3	Upstream tapping	
	5.3.4.4	Throat tapping	
	5.3.5	Coefficients	
	5.3.5.1	Limits of use	

	5.3.5.2	Discharge coefficient, C	
	5.3.5.3	Expansibility [expansion] factor, ε	
	5.3.6	Uncertainties	
	5.3.6.1	Uncertainty of discharge coefficient C	
	5.3.6.2	Uncertainty of expansibility [expansion] factor ε	
	5.3.7	Calibration and extrapolation	
	5.3.8	Pressure Loss	
	5.4	Venturi nozzles	
	5.4.1	General shape	
	5.4.2	Material and manufacture	
	5.4.3	Pressure tappings	
	5.4.3.1	Angular position of the pressure tappings	
	5.4.3.2	Upstream pressure tappings	
	5.4.3.3	Throat pressure tappings	
	5.4.4	Coefficients	
	5.4.4.1	Limits of use	
	5.4.4.2	Discharge coefficient, C	
	5.4.4.3	Expansibility [expansion] factor, ε	
	5.4.5	Uncertainties	
	5.4.5.1	Uncertainty of discharge coefficient C	
	5.4.5.2	Uncertainty of expansibility [expansion] factor ε	
	5.4.6	Pressure loss	
6	Install	Installation requirements	
	6.1	General	
	6.2	Minimum upstream and downstream straight lengths for installation between various	
		fittings and the primary device	
	6.3	Flow conditioners	
	6.4	Circularity and cylindricality of the pipe	
	6.5	Location of primary device and carrier rings	
	6.6	Method of fixing and gaskets	
7	Flour		
'	Flow calibration of nozzles		
	7.1	General	
	7.2	Test facility	
	7.3	Meter installation	
	7.4	Design of the test programme	
	7.5	Reporting the calibration results	
	7.6	Uncertainty analysis of the calibration	
	7.6.1	General	
	7.6.2	Uncertainty of the test facility	
	7.6.3	Uncertainty of the nozzle	
Annex A (informative) Tables of discharge coefficients and expansibility [expansion] factors			

Annex A (informative) Tables of discharge coefficients and expansibility [expansion] factors

Annex B (informative) Akashi type (Mitsubishi type) flow conditioner

Page count: 43