DIN EN ISO 14403-2:2012-10 (E)

Water quality - Determination of total cyanide and free cyanide using flow analysis (FIA and CFA) - Part 2: Method using continuous flow analysis (CFA) (ISO 14403-2:2012)

Contents

Page

Foreword 3

Introduction 4

1 Scope 5

2 Normative references 5

3 Terms and definitions 5

4 Interferences 6
4.1 Interferences by oxidizing agents 6
4.2 Interferences by sulfide, sulfite, nitrite and carbonyl compounds 6
4.3 Other interferences 6

5 Principle 7
5.1 Determination of total cyanide 7
5.2 Determination of free cyanide 7

6 Reagents 7

7 Apparatus 10

8 Sampling and sample preparation 12

9 Procedure 13
9.1 Flow system set-up 13
9.2 Reagent blank measurement 13
9.3 Checking the suitability of the flow system 14
9.4 Calibration 14
9.5 Sample measurement 15

10 Calculation 15

11 Expression of results 15

12 Test report 15

Annex A (informative) Examples of flow systems 17

Annex B (normative) Determination of the real cyanide concentration in the potassium cyanide solution 20

Annex C (informative) Example for the determination of total cyanide and free cyanide by continuous flow analysis (CFA) with gas diffusion and amperometric detection 21

Annex D (informative) Performance data 23

Bibliography 25