

# ISO 5222-3:2026-01 (E)

## Heat recovery ventilators and energy recovery ventilators - Testing and calculating methods for performance factor - Part 3: Annual sensible heating and cooling recovery performance factors of heat recovery ventilators (HRVs)

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>4</b>	<b>Symbols .....</b>	<b>2</b>
<b>5</b>	<b>Tests .....</b>	<b>2</b>
5.1	General requirements .....	2
5.2	Test conditions .....	2
5.3	Test methods .....	3
5.3.1	General .....	3
5.3.2	Energy saving stage limit temperature .....	3
5.3.3	Sensible heating and cooling recovery performance test .....	3
5.3.4	Determination of bypass outdoor temperature .....	3
5.3.5	Measurement of power input of heat recovery ventilator with bypass ventilation function ..	3
5.3.6	Measurement of power input of heat recovery ventilator with no bypass ventilation function .....	3
<b>6</b>	<b>Calculations .....</b>	<b>3</b>
6.1	Gross sensible heating and cooling recovery effectiveness .....	3
6.2	Calculation of performance factor of annual sensible heating and cooling recovery (Fa) ....	3
6.2.1	Characteristics of annual sensible recovery capacity against outdoor temperature .....	3
6.2.2	Power input characteristics of annual sensible heating and cooling recovery against outdoor temperature .....	4
6.2.3	Outdoor temperature bin distribution for annual heating and cooling .....	4
6.2.4	Calculation of annual sensible heating and cooling recovery capacity (Ea) .....	4
6.2.5	Calculation of annual sensible heating and cooling recovery power input (Pin,E,a) .....	5
6.2.6	Calculation of performance factor for annual sensible heating and cooling recovery (Fa) ...	5
<b>7</b>	<b>Test report .....</b>	<b>5</b>
<b>Annex A (informative) The schematic diagram of HRVs' operation .....</b>		<b>7</b>
<b>Annex B (informative) Default outdoor temperature bin distribution .....</b>		<b>10</b>
<b>Annex C (informative) Calculating method for annual performance factor when setting a specific application annual load .....</b>		<b>11</b>
<b>Annex D (informative) Report template .....</b>		<b>13</b>