ISO/IEC 18092:2013-03 (E)

Information technology - Telecommunications and information exchange between systems - Near Field Communication - Interf ace and Protocol (NFCIP-1)

Contents

Page

Foreword v

Introduction vi

1 Scope 1

2 Conformance 1

3 Normative references 1

4 Terms and definitions 2

5 Conventions and notations 4
5.1 Representation of numbers 4
5.2 Names 4

6 Abbreviated terms 4

7 General 5

8 RF field 6
8.1 Values 6
8.2 Passive communication Mode 6
8.3 Active communication Mode 6
8.4 External RF field detection 6

9 RF Signal Interface 6
9.1 Bit duration 6
9.2 Active communication mode 7
9.2.1 Requirements for fc/128 7
9.2.2 Requirements for fc/64 and fc/32 7
9.3 Passive communication mode 8
9.3.1 Initiator to Target requirements for fc/128 8
9.3.2 Target to Initiator requirements for fc/128 9
9.3.3 Initiator to Target requirements for fc/64 and fc/32 9
9.3.4 Target to Initiator requirements for fc/64 and fc/32 9

10 General Protocol flow 10

11 Initialisation 10
11.1 RF Collision Avoidance 11
11.1.1 Initial RF Collision Avoidance 11
11.1.2 Response RF Collision Avoidance 12
11.2 Passive communication mode 13
11.2.1 Initialisation and Single Device Detection at fc/128 13
11.2.2 Initialisation and SDD at fc/64 and fc/32 13
11.3 Active communication mode 17
11.3.1 Initialisation at fc/128, fc/64, and fc/32 17
11.3.2 Active communication mode RF Collision Avoidance 17

12 Transport Protocol 18

12.1 Transport Data 18
12.2 Passive communication mode Activation flow 18
12.3 Active communication mode Activation flow 19
12.4 Commands 22
12.5 Activation of the protocol 22
12.5.1 Attribute Request and Response Commands 22
12.5.2 Wakeup Request and Response Commands 28
12.5.3 Parameter Selection Request and Response Commands 30
12.6 Data Exchange Protocol 33
12.6.1 Data Exchange Protocol Request and Response 33
12.6.2 Response timeout extension 37
12.6.3 Attention - Target present 37
12.6.4 Protocol operation 37
12.6.5 Multi Activation 37
12.6.6 More information (Chaining) 38
12.7 Deactivation of the protocol 38
12.7.1 Deselect Request and Response command 39
12.7.2 Release Request and Response commands 40

Annex A (normative) CRC calculation 42

A.1 CRC for Active and Passive communication mode at fc/128 42
A.2 Example of CRC calculation at fc/128 42
A.3 CRC for Active and Passive communication mode at fc/64 and fc/32 43
A.4 Example of CRC calculation at fc/64 and fc/32 43

Annex B (informative) SAK 44