

# ISO 7870-4:2021-09 (E)

## Control charts - Part 4: Cumulative sum charts

---

<b>Contents</b>		<b>Page</b>
Foreword .....		v
Introduction .....		vi
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions, abbreviated terms and symbols .....</b>	<b>1</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>3.2</b>	<b>Abbreviated terms .....</b>	<b>2</b>
<b>3.3</b>	<b>Symbols .....</b>	<b>2</b>
<b>4</b>	<b>Principal features of cumulative sum (CUSUM) charts .....</b>	<b>3</b>
<b>5</b>	<b>Basic steps in the construction of CUSUM charts -- Graphical representation .....</b>	<b>4</b>
<b>6</b>	<b>Example of a CUSUM plot -- Motor voltages .....</b>	<b>5</b>
<b>6.1</b>	<b>Process .....</b>	<b>5</b>
<b>6.2</b>	<b>Simple plot of results .....</b>	<b>5</b>
<b>6.3</b>	<b>Standard control chart for individual results .....</b>	<b>6</b>
<b>6.4</b>	<b>CUSUM chart construction .....</b>	<b>7</b>
<b>7</b>	<b>Fundamentals of making CUSUM-based decisions .....</b>	<b>8</b>
<b>7.1</b>	<b>Need for decision rules .....</b>	<b>8</b>
<b>7.2</b>	<b>Basis for making decisions .....</b>	<b>8</b>
<b>7.3</b>	<b>Measuring the effectiveness of a decision rule .....</b>	<b>9</b>
<b>7.3.1</b>	<b>Basic concepts .....</b>	<b>9</b>
<b>7.3.2</b>	<b>Example of calculation of ARL .....</b>	<b>10</b>
<b>8</b>	<b>Types of CUSUM decision schemes .....</b>	<b>10</b>
<b>8.1</b>	<b>V-mask .....</b>	<b>10</b>
<b>8.1.1</b>	<b>Configuration and dimensions .....</b>	<b>10</b>
<b>8.1.2</b>	<b>Application of the V-mask .....</b>	<b>11</b>
<b>8.1.3</b>	<b>Average run lengths .....</b>	<b>14</b>
<b>8.1.4</b>	<b>General comments on average run lengths .....</b>	<b>15</b>
<b>8.2</b>	<b>Fast-initial response (FIR) CUSUM .....</b>	<b>16</b>
<b>8.3</b>	<b>Tabular CUSUM .....</b>	<b>16</b>
<b>8.3.1</b>	<b>Rationale .....</b>	<b>16</b>
<b>8.3.2</b>	<b>Deployment .....</b>	<b>17</b>
<b>9</b>	<b>CUSUM methods for process and quality control .....</b>	<b>19</b>
<b>9.1</b>	<b>Nature of the changes to be detected .....</b>	<b>19</b>
<b>9.1.1</b>	<b>Size of the changes to be detected .....</b>	<b>19</b>
<b>9.1.2</b>	<b>'Step' changes .....</b>	<b>19</b>
<b>9.1.3</b>	<b>Drifting .....</b>	<b>19</b>
<b>9.1.4</b>	<b>Cyclic .....</b>	<b>19</b>
<b>9.1.5</b>	<b>Hunting .....</b>	<b>19</b>
<b>9.2</b>	<b>Selecting target values .....</b>	<b>19</b>
<b>9.2.1</b>	<b>General .....</b>	<b>19</b>
<b>9.2.2</b>	<b>Standard (given) value as target .....</b>	<b>20</b>
<b>9.2.3</b>	<b>Performance-based target .....</b>	<b>20</b>

9.3	CUSUM schemes for monitoring location .....	20
9.3.1	Standard schemes .....	20
9.3.2	Standard schemes -- Limitations .....	27
9.3.3	'Tailored' CUSUM schemes .....	27
9.4	CUSUM schemes for monitoring variation .....	28
9.4.1	General .....	28
9.4.2	CUSUM schemes for subgroup ranges .....	29
9.4.3	CUSUM schemes for subgroup standard deviations .....	32
9.5	Special situations .....	36
9.5.1	Large between-subgroup variation .....	36
9.5.2	'One-at-a-time' data .....	36
9.5.3	Serial dependence between observations .....	36
9.5.4	Outliers .....	37
9.6	CUSUM schemes for discrete data .....	38
9.6.1	Event count -- Poisson data .....	38
9.6.2	Two classes data -- Binomial data .....	40
Annex A (informative)ExampleoftabularCUSUM .....		44
Annex B (informative) Estimation of the change point when a step change occurs .....		48
Bibliography .....		50