

# DIN EN ISO 13297:2021-07 (E)

Small craft - Electrical systems - Alternating and direct current installations (ISO 13297:2020)

---

<b>Contents</b>	<b>Page</b>
European foreword.....	4
Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of Directive 2013/53/EU aimed to be covered.....	5
Foreword .....	6
1 Scope.....	7
2 Normative references.....	7
3 Terms and definitions .....	7
4 General requirements, DC and AC systems.....	11
5 General requirements, DC systems.....	12
6 General requirements, AC systems.....	13
7 Marking, AC systems .....	14
8 Batteries, DC systems.....	15
9 Battery-disconnect switch, DC systems.....	17
10 Power source options, AC systems.....	17
11 Inverters and inverter/chargers, AC systems.....	18
12 Overcurrent protection, DC systems.....	19
13 Overcurrent protection, AC systems .....	20
13.1 General.....	20
13.2 Supply circuits.....	20
13.3 Branch circuits .....	20
14 Ground-fault protection/earth-leakage protection, AC systems.....	21
15 Panel boards (switchboards), DC and AC systems .....	21
16 Panel boards (switchboards), AC systems .....	21
17 Conductors, DC and AC systems .....	21
18 Conductors, DC systems .....	22
19 Conductors, AC systems .....	22
20 System wiring, DC and AC systems.....	23
21 System wiring, DC systems .....	25
22 Socket outlets, DC systems.....	25
23 Socket outlets, AC systems .....	25
24 Appliances and equipment, AC systems.....	26
25 Ignition protection, DC and AC systems .....	26
26 Owner's manual.....	26

<b>Annex A (normative) Conductor requirements.....</b>	<b>27</b>
<b>Annex B (normative) Instructions to be included with owner’s manual.....</b>	<b>29</b>
<b>Annex C (informative) Recommended system tests.....</b>	<b>30</b>
<b>Annex D (informative) Typical AC system diagrams .....</b>	<b>31</b>
<b>Annex E (informative) Overcurrent protection location options.....</b>	<b>38</b>
<b>Bibliography .....</b>	<b>40</b>