

# DIN EN ISO 13297:2025-04 (E)

Small craft - Electrical systems - Alternating and direct current installations (ISO 13297:2020 + Amd 1:2022) (includes Amendment :2022)

---

<b>Contents</b>	<b>Page</b>
European foreword .....	4
<b>A1</b> European foreword to Amendment 1 <b>A1</b> .....	5
<b>A11</b> European foreword to Amendment 11 <b>A11</b> .....	6
<b>Annex ZA</b> (informative) <b>Relationship between this European Standard and the Essential Requirements of Directive 2013/53/EU aimed to be covered</b> .....	7
Foreword .....	9
<b>A1</b> Foreword to Amendment 1 <b>A1</b> .....	10
<b>1</b> Scope .....	11
<b>2</b> Normative references .....	11
<b>3</b> Terms and definitions .....	11
<b>4</b> General requirements, DC and AC systems .....	15
<b>5</b> General requirements, DC systems .....	16
<b>6</b> General requirements, AC systems .....	17
<b>7</b> Marking, AC systems .....	18
<b>8</b> Batteries, DC systems .....	19
<b>9</b> Battery-disconnect switch, DC systems .....	21
<b>10</b> Power source options, AC systems .....	21
<b>11</b> Inverters and inverter/chargers, AC systems .....	22
<b>12</b> Overcurrent protection, DC systems .....	23
<b>13</b> Overcurrent protection, AC systems .....	24
13.1 General .....	24
13.2 Supply circuits .....	24
13.3 Branch circuits .....	24
<b>14</b> Ground-fault protection/earth-leakage protection, AC systems .....	25
<b>15</b> Panel boards (switchboards), DC and AC systems .....	25
<b>16</b> Panel boards (switchboards), AC systems .....	25
<b>17</b> Conductors, DC and AC systems .....	25
<b>18</b> Conductors, DC systems .....	26
<b>19</b> Conductors, AC systems .....	26
<b>20</b> System wiring, DC and AC systems .....	27
<b>21</b> System wiring, DC systems .....	29
<b>22</b> Socket outlets, DC systems .....	29
<b>23</b> Socket outlets, AC systems .....	29
<b>24</b> Appliances and equipment, AC systems .....	29

<b>25</b>	<b>Ignition protection, DC and AC systems</b> .....	<b>30</b>
<b>26</b>	<b>Owner's manual</b> .....	<b>30</b>
<b>Annex A</b>	<b>(normative) Conductor requirements</b> .....	<b>31</b>
<b>Annex B</b>	<b>(normative) Instructions to be included with owner's manual</b> .....	<b>33</b>
<b>Annex C</b>	<b>(informative) Recommended system tests</b> .....	<b>34</b>
<b>Annex D</b>	<b>(informative) Typical AC system diagrams</b> .....	<b>35</b>
<b>Annex E</b>	<b>(informative) Overcurrent protection location options</b> .....	<b>42</b>
<b>Bibliography</b>	.....	<b>44</b>