

ISO/IEC 29341-6-13:2008-11 (E)

Information technology_ - UPnP Device Architecture_ - Part_6-13: Heating, Ventilation, and Air Conditioning Device Control Protocol_ - House Status Service

CONTENTS

- FOREWORD4
- ORIGINAL UPNP DOCUMENTS (informative)6
- 1. Overview and Scope.....8**
- 2. Service Modeling Definitions9**
 - 2.1. Service Type9
 - 2.2. State Variables9
 - 2.2.1. OccupancyState.....9
 - 2.2.2. ActivityLevel9
 - 2.2.3. DormancyLevel10
 - 2.2.4. Relationships Between State Variables10
 - 2.3. Eventing and Moderation11
 - 2.3.1. Event Model11
 - 2.4. Actions.....12
 - 2.4.1. GetOccupancyState12
 - 2.4.2. GetActivityLevel12
 - 2.4.3. GetDormancyLevel13
 - 2.4.4. SetOccupancyState13
 - 2.4.5. SetActivityLevel14
 - 2.4.6. SetDormancyLevel.....14
 - 2.4.7. Non-Standard Actions Implemented by a UPnP Vendor15
 - 2.4.8. Common Error Codes.....15
 - 2.5. Theory of Operation16
 - 2.6. Synchronization of Multiple Instances16
- 3. XML Service Description.....18**
- 4. Test20**

LIST OF TABLES

- Table 1: State Variables9
- Table 2: AllowedValueList for ActivityLevel10
- Table 3: DefaultValue for ActivityLevel10
- Table 4: AllowedValueList for DormancyLevel10
- Table 5: DefaultValue for DormancyLevel10
- Table 6: Event Moderation.....11
- Table 7: Actions12
- Table 8: Arguments for GetOccupancyState.....12
- Table 9: Arguments for GetActivityLevel12
- Table 10: Arguments for GetDormancyLevel13
- Table 11: Arguments for SetOccupancyState13
- Table 12: Arguments for SetActivityLevel.....14
- Table 13: Arguments for SetDormancyLevel.....14
- Table 14: Common Error Codes.....15