

# ISO/IEC 29341-6-13:2008-11 (E)

## Information technology\_ - UPnP Device Architecture\_ - Part\_6-13: Heating, Ventilation, and Air Conditioning Device Control Protocol\_ - House Status Service

---

### CONTENTS

- FOREWORD .....4
- ORIGINAL UPNP DOCUMENTS (informative) .....6
- 1. Overview and Scope.....8**
- 2. Service Modeling Definitions .....9**
  - 2.1. Service Type .....9
  - 2.2. State Variables .....9
    - 2.2.1. OccupancyState.....9
    - 2.2.2. ActivityLevel .....9
    - 2.2.3. DormancyLevel .....10
    - 2.2.4. Relationships Between State Variables .....10
  - 2.3. Eventing and Moderation .....11
    - 2.3.1. Event Model .....11
  - 2.4. Actions.....12
    - 2.4.1. GetOccupancyState .....12
    - 2.4.2. GetActivityLevel .....12
    - 2.4.3. GetDormancyLevel .....13
    - 2.4.4. SetOccupancyState .....13
    - 2.4.5. SetActivityLevel .....14
    - 2.4.6. SetDormancyLevel.....14
    - 2.4.7. Non-Standard Actions Implemented by a UPnP Vendor .....15
    - 2.4.8. Common Error Codes.....15
  - 2.5. Theory of Operation .....16
  - 2.6. Synchronization of Multiple Instances .....16
- 3. XML Service Description.....18**
- 4. Test .....20**

### LIST OF TABLES

- Table 1: State Variables .....9
- Table 2: AllowedValueList for ActivityLevel .....10
- Table 3: DefaultValue for ActivityLevel .....10
- Table 4: AllowedValueList for DormancyLevel .....10
- Table 5: DefaultValue for DormancyLevel .....10
- Table 6: Event Moderation.....11
- Table 7: Actions .....12
- Table 8: Arguments for GetOccupancyState.....12
- Table 9: Arguments for GetActivityLevel .....12
- Table 10: Arguments for GetDormancyLevel .....13
- Table 11: Arguments for SetOccupancyState .....13
- Table 12: Arguments for SetActivityLevel.....14
- Table 13: Arguments for SetDormancyLevel.....14
- Table 14: Common Error Codes.....15