ISO/IEC 29341-8-14:2008-11 (E)

Information technology_- UPnP Device Architecture_- Part_8-14: Internet Gateway Device Control Protocol_- Wide Area Network Cable Link Configuration Service

CONTENTS

FOREWORD 4
ORIGINAL UPNP DOCUMENTS (informative) 6
1. Overview and Scope 8
2. Service Modeling Definitions 9
2.1. ServiceType 9
2.2. State Variables 9
2.2.1. CableLinkConfigState 10
2.2.2. LinkType 11
2.2.3. DownstreamFrequency 11
2.2.4. DownstreamModulation 11
2.2.5. UpstreamFrequency 11
2.2.6. UpstreamModulation 11
2.2.7. UpstreamChannelID 11
2.2.8. UpstreamPowerLevel 11
2.2.9. BPIEncryptionEnabled 11
2.2.10. ConfigFile 11
2.2.11. TFTPServer 11
2.2.12. Relationships Between State Variables 11
2.3. Eventing and Moderation 12
2.3.1. Event Model 12
2.4. Actions 13
2.4.1. GetCableLinkConfigInfo 13
2.4.2. GetDownstreamFrequency 14
2.4.3. GetDownstreamModulation 14
2.4.4. GetUpstreamFrequency 15
2.4.5. GetUpstreamModulation 15
2.4.6. GetUpstreamChannelID 16
2.4.7. GetUpstreamPowerLevel 16
2.4.8. GetBPIEncryptionEnabled 17
2.4.9. GetConfigFile 17
2.4.10. GetTFTPServer 18
2.4.11. Non-Standard Actions Implemented by a UPnP Vendor 18
2.4.12. Relationships Between Actions 18
2.4.13. Common Error Codes 18
2.5. Theory of Operation 19
2.5.1. Connection Initiation 19
2.5.2. Deployment Scenarios 22
3. XML Service Description 23
4. Test 26

LIST OF TABLES

Table 1: State Variables 9
Table 1.1: AllowedValueList for `CableLinkConfigState` 10
Table 1.2: AllowedValueList for `LinkType` 10
Table 1.3: AllowedValueList for `DownstreamModulation` 10
Table 1.4: AllowedValueList for `UpstreamModulation` 10
Table 2: Event Moderation 12
Table 3: Actions 13
Table 4: Arguments for `GetCableLinkConfigInfo` 13
Table 5: Arguments for `Get GetDownstreamFrequency` 14
Table 6: Arguments for `GetDownstreamModulation` 14
Table 7: Arguments for `GetUpstreamFrequency` 15
Table 8: Arguments for `GetUpstreamModulation` 15
Table 9: Arguments for `GetUpstreamChannelID` 16
Table 10: Arguments for `GetUpstreamPowerLevel` 16
Table 11: Arguments for `GetBPIEncryptionEnabled` 17
Table 12: Arguments for `GetConfigFile` 17
Table 13: Arguments for `GetTFTPServer` 18
Table 14: Common Error Codes 18