

ISO/IEC 29341-9-11:2008-11 (E)

Information technology_ - UPnP Device Architecture_ - Part_9-11: Imaging Device Control Protocol_ - Feeder Service

CONTENTS

- FOREWORD4
- ORIGINAL UPNP DOCUMENTS (informative)6
- 1. Overview and Scope8**
- 2. Service Modeling Definitions9**
 - 2.1. ServiceType9
 - 2.2. Service State Table9
 - 2.2.1. Model9
 - 2.2.2. State9
 - 2.2.3. FailureCode10
 - 2.2.4. MorePages10
 - 2.2.5. FeederMode10
 - 2.2.6. SheetWidth10
 - 2.2.7. SheetHeight11
 - 2.2.8. InputJustification11
 - 2.2.9. JobID11
 - 2.2.10. EntireDocument11
 - 2.2.11. Timeout11
 - 2.3. Eventing and Moderation12
 - 2.4. Actions13
 - 2.4.1. *(void)* Load(JobIDIn, StateOut)13
 - 2.4.2. *(void)* Eject(JobIDIn, bEntireDocumentIn, StateOut)14
 - 2.4.3. *(void)* Reset(JobIDIn, StateOut)14
 - 2.4.4. *(void)* GetState(StateOut, MorePagesOut, FailureCodeOut)15
 - 2.4.5. *(void)* SetFeederMode(JobIDIn, FeederModeIn)15
 - 2.4.6. *(void)* GetFeederMode(FeederModeOut)15
 - 2.4.7. Common Error Codes16
 - 2.5. Theory of Operation16
 - 2.5.1. Enhanced Feeder Operation17
- 3. XML Service Template for Feeder:1.018**
- 4. Testing22**
 - 4.1. Syntax Tests22

LIST OF TABLES

Table 1: State Variables	9
Table 1.1 <i>allowedValueList</i> for <i>State</i>	10
Table 1.2 <i>allowedValueList</i> for <i>FailureCode</i>	10
Table 1.3 <i>allowedValueList</i> for <i>FeederMode</i>	10
Table 1.4 <i>allowedValueRange</i> for <i>SheetWidth</i>	10
Table 1.5 <i>allowedValueRange</i> for <i>SheetHeight</i>	11
Table 2: Event Moderation.....	12
Table 3: Action List	13
Table 4: Arguments for Load	13
Table 5: Errors for Load.....	13
Table 6: Arguments for Eject.....	14
Table 7: Errors for Eject.....	14
Table 8: Arguments for Reset.....	14
Table 9: Errors for Reset	14
Table 10: Arguments for GetState.....	15
Table 11: Arguments for SetFeederMode	15
Table 12: Errors for SetFeederMode.....	15
Table 13: Arguments for GetFeederMode.....	15
Table 14: Common Error Codes.....	16