

# ISO/IEC 29341-9-11:2008-11 (E)

## Information technology\_ - UPnP Device Architecture\_ - Part\_9-11: Imaging Device Control Protocol\_ - Feeder Service

---

### CONTENTS

- FOREWORD .....4
- ORIGINAL UPNP DOCUMENTS (informative) .....6
- 1. Overview and Scope .....8**
- 2. Service Modeling Definitions .....9**
  - 2.1. ServiceType .....9
  - 2.2. Service State Table .....9
    - 2.2.1. Model .....9
    - 2.2.2. State .....9
    - 2.2.3. FailureCode .....10
    - 2.2.4. MorePages .....10
    - 2.2.5. FeederMode .....10
    - 2.2.6. SheetWidth .....10
    - 2.2.7. SheetHeight .....11
    - 2.2.8. InputJustification .....11
    - 2.2.9. JobID .....11
    - 2.2.10. EntireDocument .....11
    - 2.2.11. Timeout .....11
  - 2.3. Eventing and Moderation .....12
  - 2.4. Actions .....13
    - 2.4.1. *(void)* Load(JobIDIn, StateOut) .....13
    - 2.4.2. *(void)* Eject(JobIDIn, bEntireDocumentIn, StateOut) .....14
    - 2.4.3. *(void)* Reset(JobIDIn, StateOut) .....14
    - 2.4.4. *(void)* GetState(StateOut, MorePagesOut, FailureCodeOut) .....15
    - 2.4.5. *(void)* SetFeederMode(JobIDIn, FeederModeIn) .....15
    - 2.4.6. *(void)* GetFeederMode(FeederModeOut) .....15
    - 2.4.7. Common Error Codes .....16
  - 2.5. Theory of Operation .....16
    - 2.5.1. Enhanced Feeder Operation .....17
- 3. XML Service Template for Feeder:1.0 .....18**
- 4. Testing .....22**
  - 4.1. Syntax Tests .....22

## LIST OF TABLES

Table 1: State Variables .....	9
Table 1.1 <i>allowedValueList</i> for <i>State</i> .....	10
Table 1.2 <i>allowedValueList</i> for <i>FailureCode</i> .....	10
Table 1.3 <i>allowedValueList</i> for <i>FeederMode</i> .....	10
Table 1.4 <i>allowedValueRange</i> for <i>SheetWidth</i> .....	10
Table 1.5 <i>allowedValueRange</i> for <i>SheetHeight</i> .....	11
Table 2: Event Moderation.....	12
Table 3: Action List .....	13
Table 4: Arguments for Load .....	13
Table 5: Errors for Load.....	13
Table 6: Arguments for Eject.....	14
Table 7: Errors for Eject.....	14
Table 8: Arguments for Reset.....	14
Table 9: Errors for Reset .....	14
Table 10: Arguments for GetState.....	15
Table 11: Arguments for SetFeederMode .....	15
Table 12: Errors for SetFeederMode.....	15
Table 13: Arguments for GetFeederMode.....	15
Table 14: Common Error Codes.....	16