

# ISO/IEC 29341-9-11:2008-11 (E)

## Information technology\_ - UPnP Device Architecture\_ - Part\_9-11: Imaging Device Control Protocol\_ - Feeder Service

---

### CONTENTS

FOREWORD .....	4
ORIGINAL UPNP DOCUMENTS (informative) .....	6
<b>1. Overview and Scope .....</b>	<b>8</b>
<b>2. Service Modeling Definitions .....</b>	<b>9</b>
2.1. ServiceType .....	9
2.2. Service State Table .....	9
2.2.1. Model .....	9
2.2.2. State .....	9
2.2.3. FailureCode .....	10
2.2.4. MorePages .....	10
2.2.5. FeederMode .....	10
2.2.6. SheetWidth .....	10
2.2.7. SheetHeight .....	11
2.2.8. InputJustification .....	11
2.2.9. JobID .....	11
2.2.10. EntireDocument .....	11
2.2.11. Timeout .....	11
2.3. Eventing and Moderation .....	12
2.4. Actions .....	13
2.4.1. <i>(void)</i> Load(JobIDIn, StateOut) .....	13
2.4.2. <i>(void)</i> Eject(JobIDIn, bEntireDocumentIn, StateOut) .....	14
2.4.3. <i>(void)</i> Reset(JobIDIn, StateOut) .....	14
2.4.4. <i>(void)</i> GetState(StateOut, MorePagesOut, FailureCodeOut) .....	15
2.4.5. <i>(void)</i> SetFeederMode(JobIDIn, FeederModeIn) .....	15
2.4.6. <i>(void)</i> GetFeederMode(FeederModeOut) .....	15
2.4.7. Common Error Codes .....	16
2.5. Theory of Operation .....	16
2.5.1. Enhanced Feeder Operation .....	17
<b>3. XML Service Template for <u>Feeder:1.0</u> .....</b>	<b>18</b>
<b>4. Testing .....</b>	<b>22</b>
4.1. Syntax Tests .....	22

## LIST OF TABLES

Table 1: State Variables .....	9
Table 1.1 <i>allowedValueList</i> for <i>State</i> .....	10
Table 1.2 <i>allowedValueList</i> for <i>FailureCode</i> .....	10
Table 1.3 <i>allowedValueList</i> for <i>FeederMode</i> .....	10
Table 1.4 <i>allowedValueRange</i> for <i>SheetWidth</i> .....	10
Table 1.5 <i>allowedValueRange</i> for <i>SheetHeight</i> .....	11
Table 2: Event Moderation.....	12
Table 3: Action List .....	13
Table 4: Arguments for Load .....	13
Table 5: Errors for Load.....	13
Table 6: Arguments for Eject.....	14
Table 7: Errors for Eject.....	14
Table 8: Arguments for Reset.....	14
Table 9: Errors for Reset .....	14
Table 10: Arguments for GetState.....	15
Table 11: Arguments for SetFeederMode .....	15
Table 12: Errors for SetFeederMode.....	15
Table 13: Arguments for GetFeederMode.....	15
Table 14: Common Error Codes.....	16