

# ISO 11665-3:2020-01 (E)

## Measurement of radioactivity in the environment - Air: radon-222 - Part 3: Spot measurement method of the potential alpha energy concentration of its short-lived decay products

---

Contents		Page
Foreword		iv
Introduction		v
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions and symbols</b>	<b>1</b>
3.1	Terms and definitions	1
3.2	Symbols	2
<b>4</b>	<b>Principle of the measurement method</b>	<b>3</b>
<b>5</b>	<b>Equipment</b>	<b>3</b>
<b>6</b>	<b>Sampling</b>	<b>4</b>
6.1	General	4
6.2	Sampling objective	4
6.3	Sampling characteristics	4
6.4	Sampling conditions	5
6.4.1	General	5
6.4.2	Installation of sampling system	5
6.4.3	Sampling duration	5
6.4.4	Volume of air sampled	5
<b>7</b>	<b>Detection method</b>	<b>5</b>
<b>8</b>	<b>Measurement</b>	<b>5</b>
8.1	Procedure	5
8.2	Influence quantities	6
8.3	Calibration	6
<b>9</b>	<b>Expression of results</b>	<b>7</b>
9.1	General	7
9.2	Potential alpha energy concentration	7
9.3	Standard uncertainty	7
9.4	Decision threshold	8
9.5	Detection limit	9
9.6	Limits of the confidence interval	9
<b>10</b>	<b>Test report</b>	<b>9</b>
<b>Annex A (informative)</b>	<b>Examples of gross alpha counting protocols</b>	<b>11</b>
<b>Annex B (informative)</b>	<b>Calculation of the coefficients <math>k_{218\text{Po},j}</math>, <math>k_{214\text{Pb},j}</math> and <math>k_{214\text{Bi},j}</math></b>	<b>12</b>
<b>Annex C (informative)</b>	<b>Measurement method using gross alpha counting according to the Thomas protocol</b>	<b>16</b>
<b>Bibliography</b>		<b>19</b>