

# ISO/IEC 9318-4:2002-12 (E)

## Information technology - Intelligent peripheral interface - Part 4: Device generic command set for magnetic tape drives (IPI-3\_tape)

---

### CONTENTS

- FOREWORD ..... 8
- INTRODUCTION ..... 9
- 1 Scope ..... 10
- 2 Normative references ..... 11
- 3 Definitions and conventions ..... 11
  - 3.1 Definitions ..... 11
  - 3.2 Conventions ..... 13
- 4 Logical interface characteristics of the tape ..... 13
  - 4.1 PhysicalBlocks ..... 13
  - 4.2 DataBlocks ..... 14
  - 4.3 Extents ..... 14
  - 4.4 Partitions ..... 14
  - 4.5 Alternate data areas ..... 15
  - 4.6 Partition parameters ..... 15
  - 4.7 Block numbering ..... 15
  - 4.8 Data buffer operation ..... 15
  - 4.9 Positioning ..... 16
    - 4.9.0 General ..... 16
    - 4.9.1 Mount or rewind ..... 16
    - 4.9.2 Partition transition ..... 16
    - 4.9.3 Normal data operation completion ..... 16
    - 4.9.4 Abnormal data operation completion ..... 17
    - 4.9.5 Normal position operation completion ..... 17
    - 4.9.6 Abnormal position operation completion ..... 17
    - 4.9.7 Tape mark detected ..... 17
    - 4.9.8 BOM detected (reverse operations) ..... 17
    - 4.9.9 EMW detected ..... 17
    - 4.9.10 PEOM detected ..... 17
  - 4.10 Attributes usage ..... 17
  - 4.11 Command usage ..... 18
- 5 Message packet structure ..... 18
- 6 Control commands ..... 18
  - 6.0 General ..... 18
  - 6.1 NOP ..... 18
  - 6.2 FACILITY OPERATION ..... 18
  - 6.3 ATTRIBUTES ..... 18
    - 6.3.1 Command packet ..... 18
    - 6.3.2 Response packet ..... 19
    - 6.3.3 Description ..... 19
    - 6.3.4 Parameters ..... 21
  - 6.4 REPORT ADDRESSEE STATUS ..... 32
    - 6.4.1 Command packet ..... 32
    - 6.4.2 Response packet ..... 32
    - 6.4.3 Description ..... 32

6.4.4	Parameters 50 to 53 .....	32
6.5	PORT ADDRESS.....	33
6.6	PATH CONTROL.....	33
6.7	ATTENTION CONTROL.....	33
6.8	OPERATING MODE .....	34
6.8.1	Command packet.....	34
6.8.2	Response packet .....	34
6.8.3	Description .....	34
6.8.4	Parameters 3E, 50, 53, 54 .....	34
6.9	ABORT.....	37
6.10	ACCESS PERMITS.....	37
6.11	RESUME .....	37
6.12	PORT RESPONSE .....	38
6.13	ANTICIPATED ACTION .....	38
6.14	OPERATOR DISPLAY .....	38
7	Position commands.....	38
7.0	General .....	38
7.1	SPACE BLOCK/FILE MARK.....	38
7.1.1	Command packet.....	38
7.1.2	Response packet .....	38
7.1.3	Description .....	38
7.1.4	Parameters 31, 32, 35 .....	40
7.2	POSITION CONTROL.....	40
7.2.1	Command packet.....	40
7.2.2	Response packet .....	40
7.2.3	Description .....	41
7.2.4	Parameters 31, 32, 35, 3A, 3E, 51, 52, 53, 54, 55.....	41
7.3	REPORT POSITION .....	46
7.3.1	Command packet.....	46
7.3.2	Response packet .....	46
7.3.3	Description .....	46
7.3.4	Parameters 32, 35, 3A, 3E, 51-52 .....	47
7.4	RECORD POSITION.....	48
7.4.1	Command packet.....	48
7.4.2	Response packet .....	48
7.4.3	Description .....	48
7.4.4	Parameters 31, 32, 35, 51.....	49
7.5	Reserved .....	50
8	Transfer commands .....	50
8.0	General .....	50
8.1	READ .....	50
8.1.1	Command packet.....	50
8.1.2	Response packet .....	50
8.1.3	Description .....	50
8.1.4	Parameters 31 to 32, 3A, 35, 3E, 51, 52 .....	51
8.2	READ RAW DATA .....	53
8.2.1	Command packet.....	53
8.2.2	Response packet .....	53
8.2.3	Description .....	53

8.2.4	Parameters 31, 32, 35, 3A, 3C, 3E.....	53
8.3	Reserved.....	54
8.4	SEARCH.....	54
8.5	WRITE.....	54
8.5.1	Command packet.....	54
8.5.2	Response packet.....	55
8.5.3	Description.....	55
8.5.4	Parameters 31, 32, 35, 3A, 3C, 3E, 51, 52.....	55
8.6	WRITE PATTERN.....	56
8.7	Reserved.....	56
9	Combination commands.....	56
9.1	COPY.....	56
9.2	COMPARE SLAVE DATA.....	56
9.3	COMPARE DATA.....	56
9.4	Reserved.....	56
9.5	Reserved.....	57
9.6	SHADOW READ.....	57
9.7	SHADOW WRITE.....	57
9.8	SHADOW RESTORE.....	57
10	Other transfer commands.....	57
10.0	General.....	57
10.1	READ VERIFY.....	57
10.1.1	Command packet.....	57
10.1.2	Response packet.....	57
10.1.3	Description.....	57
10.1.4	Parameters 31, 32, 35, 3A, 3C, 3E.....	58
10.2	Reserved.....	59
10.3	READ FROM BUFFER.....	59
10.3.1	Command packet.....	59
10.3.2	Response packet.....	59
10.3.3	Description.....	59
10.3.4	Parameters 31, 32, 35, 3A, 3E, 50.....	61
10.4	READ FACILITY DATA TO BUFFER.....	61
10.5	READ PHYSICAL DATA AND ECC.....	61
10.6	READ PHYSICAL HEADER.....	62
10.7	READ IPL.....	62
10.7.1	Command packet.....	62
10.7.2	Response packet.....	62
10.7.3	Description.....	62
10.8	READ PHYSICAL HEADER AND ECC.....	62
10.9	WRITE TO BUFFER.....	62
10.10	WRITE BUFFER TO FACILITY.....	62
10.11	WRITE PHYSICAL DATA AND ECC.....	62
10.12	WRITE PHYSICAL HEADER.....	63
10.13	LOAD SLAVE IML.....	63
10.14	ERASE.....	63
10.14.1	Command packet.....	63
10.14.2	Response packet.....	63
10.14.3	Description.....	63

10.14.4	Parameters 31, 32, 35, 3A, 3E .....	64
10.15	WRITE PHYSICAL HEADER AND ECC .....	64
11	Diagnostic commands .....	64
11.0	General .....	64
11.1	PERFORM SLAVE DIAGNOSTICS .....	64
11.2	PERFORM FACILITY DIAGNOSTICS .....	65
11.3	Reserved .....	65
11.4	Reserved .....	65
11.5	READ ERROR LOG .....	65
11.5.1	Command packet .....	65
11.5.2	Response packet .....	65
11.5.3	Description .....	65
11.6	WRITE ERROR LOG .....	65
11.7	DIAGNOSTIC CONTROL .....	65
12	Command summary .....	66
12.1	Control commands .....	66
12.2	Position commands .....	67
12.3	Transfer commands .....	67
12.4	Combination commands .....	67
12.5	Other transfer commands .....	68
12.6	Diagnostic commands .....	69
Annex A (normative)	Overview: interface levels, concepts and application environments .....	70
A.1	Interface levels .....	70
A.2	Concepts .....	70
A.2.0	General .....	70
A.2.1	Relationship of master, slave and facility .....	70
A.2.2	Relationship of facilities and partitions .....	71
A.2.3	Command structure .....	71
A.3	Application environments .....	71
A.3.0	General .....	71
A.3.1	Control of facilities by the master .....	72
A.3.2	Shared control of facilities .....	72
A.3.3	Control of facilities by the slave .....	72
Figure 1	– Command packet for ATTRIBUTES .....	18
Figure 2	– Response packet for ATTRIBUTES .....	19
Figure 3	– Command packet for REPORT ADDRESSEE STATUS .....	32
Figure 4	– Response packet for REPORT ADDRESSEE STATUS .....	32
Figure 5	– Command packet for OPERATING MODE .....	34
Figure 6	– Response packet for OPERATING MODE .....	34
Figure 7	– Command packet for SPACE BLOCK/FILE MARK .....	38
Figure 8	– Response packet for SPACE BLOCK/FILE MARK .....	38
Figure 9	– Command packet for POSITION CONTROL .....	40
Figure 10	– Response packet for POSITION CONTROL .....	40
Figure 11	– Command packet for REPORT POSITION .....	46
Figure 12	– Response packet for REPORT POSITION .....	46

Figure 13 – Command packet for RECORD POSITION .....	48
Figure 14 – Response packet for RECORD POSITION.....	48
Figure 15 – Command packet for READ .....	50
Figure 16 – Response packet for READ .....	50
Figure 17 – Command packet for READ RAW DATA .....	53
Figure 18 – Response packet for READ RAW DATA .....	53
Figure 19 – Command packet for WRITE .....	54
Figure 20 – Response packet for WRITE.....	55
Figure 21 – Command packet for READ VERIFY.....	57
Figure 22 – Response packet for READ VERIFY .....	57
Figure 23 – Command packet for READ FROM BUFFER .....	59
Figure 24 – Response packet for READ FROM BUFFER.....	59
Figure 25 – Command packet for READ IPL.....	62
Figure 26 – Response packet for READ IPL .....	62
Figure 27 – Command packet for ERASE .....	63
Figure 28 – Response packet for ERASE .....	63
Figure 29 – Command packet for READ ERROR LOG.....	65
Figure 30 – Response packet for READ ERROR LOG .....	65
Table 1 – Attributes parameters 3A, 3E, 50 .....	21
Table 2 – Attributes parameters 51 to 58.....	22
Table 3 – Attributes parameters 59, 5A .....	23
Table 4 – Attributes parameters 5B to 5D.....	23
Table 5 – Attributes parameters 5E to 65 .....	23
Table 6 – Attributes parameters 66, 67.....	24
Table 7 – Attributes parameter 68 .....	24
Table 8 – Attributes parameters 69, 6A .....	24
Table 9 – Attributes parameters 6B to 6F .....	25
Table 10 – Attributes parameters 70, 71.....	25
Table 11 – Attributes parameter 72 .....	27
Table 12 – Attributes parameter 73 .....	28
Table 13 – Attributes parameters 74, 75.....	30
Table 14 – Attributes parameters 76 to 79.....	31
Table 15 – Report addressee status parameters 50 to 53.....	33
Table 16 – Operating mode parameters 3E, 50, 52 .....	35
Table 17 – Operating mode parameter 53 .....	36
Table 18 – Operating mode parameter 54 .....	37
Table 19 – Space block/file mark parameters 31, 32, 35 .....	40
Table 20 – Position control parameters 31 to 32, 35, 3A, 3E, 51 to 53.....	42
Table 21 – Position control parameters 54, 55 .....	43
Table 22 – Report position parameters 32, 35, 3A, 3E, 51, 52.....	47
Table 23 – Record position parameters 31, 32, 35, 3A, 51 .....	49

Table 24 – Read parameters 31, 32, 35, 3A, 3C, 3E, 51, 52.....	52
Table 25 – Read raw data parameters 31, 32, 35, 3A, 3C, 3E .....	54
Table 26 – Write parameters 31, 32, 35, 3A, 3C, 3E, 51, 52.....	55
Table 27 – Read verify parameters 31, 32, 35, 3A, 3C, 3E .....	58
Table 28 – Read from buffer parameters 31, 32, 35, 3A, 3E, 50 .....	61
Table 29 – Erase parameters 31, 32, 35, 3A, 3E .....	64