ISO/IEC 9318-4:2002-12 (E)

Information technology_- Intelligent peripheral interface_- Part_4: Device generic command set for magnetic tape drives (IPI-3_tape)

CONTENTS

FOREWORD 8
INTRODUCTION 9
1 Scope 10
2 Normative references 11
3 Definitions and conventions 11
3.1 Definitions 11
3.2 Conventions 13
4 Logical interface characteristics of the tape 13
4.1 PhysicalBlocks 13
4.2 DataBlocks 14
4.3 Extents 14
4.4 Partitions 14
4.5 Alternate data areas 15
4.6 Partition parameters 15
4.7 Block numbering 15
4.8 Data buffer operation 15
4.9 Positioning 16
4.9.0 General 16
4.9.1 Mount or rewind 16
4.9.2 Partition transition 16
4.9.3 Normal data operation completion 16
4.9.4 Abnormal data operation completion 17
4.9.5 Normal position operation completion 17
4.9.6 Abnormal position operation completion 17
4.9.7 Tape mark detected 17
4.9.8 BOM detected (reverse operations) 17
4.9.9 EMW detected 17
4.9.10 PEOM detected 17
4.10 Attributes usage 17
4.11 Command usage 18
5 Message packet structure 18
6 Control commands 18
6.0 General 18
6.1 NOP 18
6.2 FACILITY OPERATION 18
6.3 ATTRIBUTES 18
6.3.1 Command packet 18
6.3.2 Response packet 19
6.3.3 Description 19
6.3.4 Parameters 21
6.4 REPORT ADDRESSEE STATUS 32
6.4.1 Command packet 32
6.4.2 Response packet 32
6.4.3 Description 32

6.4.4 Parameters 50 to 53 32
6.5 PORT ADDRESS 33
6.6 PATH CONTROL 33
6.7 ATTENTION CONTROL 33
6.8 OPERATING MODE 34
6.8.1 Command packet 34
6.8.2 Response packet 34
6.8.3 Description 34
6.8.4 Parameters 3E, 50, 53, 54 34
6.9 ABORT 37
6.10 ACCESS PERMITS 37
6.11 RESUME 37
6.12 PORT RESPONSE 38
6.13 ANTICIPATED ACTION 38
6.14 OPERATOR DISPLAY 38
7 Position commands 38
7.0 General 38
7.1 SPACE BLOCK/FILE MARK 38
7.1.1 Command packet 38
7.1.2 Response packet 38
7.1.3 Description 38
7.1.4 Parameters 31, 32, 35 40
7.2 POSITION CONTROL 40
7.2.1 Command packet 40
7.2.2 Response packet 40
7.2.3 Description 41
7.2.4 Parameters 31, 32, 35, 3A, 3E, 51, 52, 53, 54, 55 41
7.3 REPORT POSITION 46
7.3.1 Command packet 46
7.3.2 Response packet 46
7.3.3 Description 46
7.3.4 Parameters 32, 35, 3A, 3E, 51-52 47
7.4 RECORD POSITION 48
7.4.1 Command packet 48
7.4.2 Response packet 48
7.4.3 Description 48
7.4.4 Parameters 31, 32, 35, 51 49
7.5 Reserved 50
8 Transfer commands 50
8.0 General 50
8.1 READ 50
8.1.1 Command packet 50
8.1.2 Response packet 50
8.1.3 Description 50
8.1.4 Parameters 31 to 32, 3A, 35, 3E, 51, 52 51
8.2 READ RAW DATA 53
8.2.1 Command packet 53
8.2.2 Response packet 53
8.2.3 Description 53

8.2.4 Parameters 31, 32, 35, 3A, 3C, 3E 53
8.3 Reserved 54
8.4 SEARCH 54
8.5 WRITE 54
8.5.1 Command packet 54
8.5.2 Response packet 55
8.5.3 Description 55
8.5.4 Parameters 31, 32, 35, 3A, 3C, 3E, 51, 52 55
8.6 WRITE PATTERN 56
8.7 Reserved 56
9 Combination commands 56
9.1 COPY 56
9.2 COMPARE SLAVE DATA 56
9.3 COMPARE DATA 56
9.4 Reserved 56
9.5 Reserved 57
9.6 SHADOW READ 57
9.7 SHADOW WRITE 57
9.8 SHADOW RESTORE 57
10 Other transfer commands 57
10.0 General 57
10.1 READ VERIFY 57
10.1.1 Command packet 57
10.1.2 Response packet 57
10.1.3 Description 57
10.1.4 Parameters 31, 32, 35, 3A, 3C, 3E 58
10.2 Reserved 59
10.3 READ FROM BUFFER 59
10.3.1 Command packet 59
10.3.2 Response packet 59
10.3.3 Description 59
10.3.4 Parameters 31, 32, 35, 3A, 3E, 50 61
10.4 READ FACILITY DATA TO BUFFER 61
10.5 READ PHYSICAL DATA AND ECC 61
10.6 READ PHYSICAL HEADER 62
10.7 READ IPL 62
10.7.1 Command packet 62
10.7.2 Response packet 62
10.7.3 Description 62
10.8 READ PHYSICAL HEADER AND ECC 62
10.9 WRITE TO BUFFER 62
10.10 WRITE BUFFER TO FACILITY 62
10.11 WRITE PHYSICAL DATA AND ECC 62
10.12 WRITE PHYSICAL HEADER 63
10.13 LOAD SLAVE IML 63
10.14 ERASE 63
10.14.1 Command packet 63
10.14.2 Response packet 63
10.14.3 Description 63

10.14.4 Parameters 31, 32, 35, 3A, 3E 64
10.15 WRITE PHYSICAL HEADER AND ECC 64
11 Diagnostic commands 64
11.0 General 64
11.1 PERFORM SLAVE DIAGNOSTICS 64
11.2 PERFORM FACILITY DIAGNOSTICS 65
11.3 Reserved 65
11.4 Reserved 65
11.5 READ ERROR LOG 65
11.5.1 Command packet 65
11.5.2 Response packet 65
11.5.3 Description 65
11.6 WRITE ERROR LOG 65
11.7 DIAGNOSTIC CONTROL 65
12 Command summary 66
12.1 Control commands 66
12.2 Position commands 67
12.3 Transfer commands 67
12.4 Combination commands 67
12.5 Other transfer commands 68
12.6 Diagnostic commands 69
Annex A (normative) Overview: interface levels, concepts and application environments 70
A.1 Interface levels 70
A.2 Concepts 70
A.2.0 General 70
A.2.1 Relationship of master, slave and facility 70
A.2.2 Relationship of facilities and partitions 71
A.2.3 Command structure 71
A.3 Application environments 71
A.3.0 General 71
A.3.1 Control of facilities by the master 72
A.3.2 Shared control of facilities 72
A.3.3 Control of facilities by the slave 72

Figure 1 – Command packet for ATTRIBUTES 18
Figure 2 – Response packet for ATTRIBUTES 19
Figure 3 – Command packet for REPORT ADDRESSEE STATUS 32
Figure 4 – Response packet for REPORT ADDRESSEE STATUS 32
Figure 5 – Command packet for OPERATING MODE 34
Figure 6 – Response packet for OPERATING MODE 34
Figure 7 – Command packet for SPACE BLOCK/FILE MARK 38
Figure 8 – Response packet for SPACE BLOCK/FILE MARK 38
Figure 9 – Command packet for POSITION CONTROL 40
Figure 10 – Response packet for POSITION CONTROL 40
Figure 11 – Command packet for REPORT POSITION 46
Figure 12 – Response packet for REPORT POSITION 46

Figure 13 – Command packet for RECORD POSITION 48
Figure 14 – Response packet for RECORD POSITION....48
Figure 15 – Command packet for READ 50
Figure 16 – Response packet for READ 50
Figure 17 – Command packet for READ RAW DATA 53
Figure 18 – Response packet for READ RAW DATA 53
Figure 19 – Command packet for WRITE 54
Figure 20 – Response packet for WRITE....55
Figure 21 – Command packet for READ VERIFY....57
Figure 22 – Response packet for READ VERIFY 57
Figure 23 – Command packet for READ FROM BUFFER 59
Figure 24 – Response packet for READ FROM BUFFER....59
Figure 25 – Command packet for READ IPL....62
Figure 26 – Response packet for READ IPL 62
Figure 27 – Command packet for ERASE....63
Figure 28 – Response packet for ERASE 63
Figure 29 – Command packet for READ ERROR LOG....65
Figure 30 – Response packet for READ ERROR LOG....65

Table 1 – Attributes parameters 3A, 3E, 50 21
Table 2 – Attributes parameters 51 to 58....22
Table 3 – Attributes parameters 59, 5A 23
Table 4 – Attributes parameters 5B to 5D....23
Table 5 – Attributes parameters 5E to 65 23
Table 6 – Attributes parameters 66, 67....24
Table 7 – Attributes parameter 68 24
Table 8 – Attributes parameters 69, 6A 24
Table 9 – Attributes parameters 6B to 6F 25
Table 10 – Attributes parameters 70, 71....25
Table 11 – Attributes parameter 72 27
Table 12 – Attributes parameter 73 28
Table 13 – Attributes parameters 74, 75....30
Table 14 – Attributes parameters 76 to 79....31
Table 15 – Report addressee status parameters 50 to 53....33
Table 16 – Operating mode parameters 3E, 50, 52 35
Table 17 – Operating mode parameter 53 36
Table 18 – Operating mode parameter 54 37
Table 19 – Space block/file mark parameters 31, 32, 35 40
Table 20 – Position control parameters 31 to 32, 35, 3A, 3E, 51 to 53....42
Table 21 – Position control parameters 54, 55 43
Table 22 – Report position parameters 32, 35, 3A, 3E, 51, 52....47
Table 23 – Record position parameters 31, 32, 35, 3A, 51 49

Table 24 – Read parameters 31, 32, 35, 3A, 3C, 3E, 51, 52 52
Table 25 – Read raw data parameters 31, 32, 35, 3A, 3C, 3E 54
Table 26 – Write parameters 31, 32, 35, 3A, 3C, 3E, 51, 52 55
Table 27 – Read verify parameters 31, 32, 35, 3A, 3C, 3E 58
Table 28 – Read from buffer parameters 31, 32, 35, 3A, 3E, 50 61
Table 29 – Erase parameters 31, 32, 35, 3A, 3E 64