

# ISO 13185-2:2015-04 (E)

## Intelligent transport systems - Vehicle interface for provisioning and support of ITS services - Part 2: Unified gateway protocol (UGP) requirements and specification for vehicle ITS station gateway (V-ITS-SG) interface

---

<b>Contents</b>		<b>Page</b>
Foreword .....		vi
Introduction .....		vii
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols, and abbreviated terms .....</b>	<b>1</b>
<b>3.1</b>	<b>Terms and definitions .....</b>	<b>1</b>
<b>3.2</b>	<b>Abbreviated terms .....</b>	<b>2</b>
<b>4</b>	<b>Conventions .....</b>	<b>3</b>
<b>5</b>	<b>Document overview .....</b>	<b>4</b>
<b>6</b>	<b>UGP application layer services .....</b>	<b>6</b>
<b>6.1</b>	<b>General .....</b>	<b>6</b>
<b>6.2</b>	<b>Service primitives .....</b>	<b>6</b>
<b>6.3</b>	<b>Application layer service primitives -- Confirmed service .....</b>	<b>7</b>
<b>6.4</b>	<b>Format description of service primitives .....</b>	<b>8</b>
<b>6.4.1</b>	<b>General definition .....</b>	<b>8</b>
<b>6.4.2</b>	<b>Service request and service indication primitives .....</b>	<b>8</b>
<b>6.4.3</b>	<b>Service response and service confirm primitives .....</b>	<b>9</b>
<b>6.4.4</b>	<b>Service request-confirm and service response-confirm primitives .....</b>	<b>10</b>
<b>6.5</b>	<b>UGP service call with global reply message handling .....</b>	<b>10</b>
<b>6.6</b>	<b>UGP service call with scheduled-based reply message handling .....</b>	<b>11</b>
<b>6.7</b>	<b>UGP service data unit specification .....</b>	<b>12</b>
<b>6.7.1</b>	<b>Mandatory parameters .....</b>	<b>12</b>
<b>7</b>	<b>UGP application layer protocol in ASN.1 document interface .....</b>	<b>13</b>
<b>7.1</b>	<b>General definition .....</b>	<b>13</b>
<b>7.2</b>	<b>Common message data and structure .....</b>	<b>13</b>
<b>7.3</b>	<b>ASN.1 model .....</b>	<b>14</b>
<b>8</b>	<b>Unified gateway protocol (UGP) clusters .....</b>	<b>15</b>
<b>8.1</b>	<b>Overview .....</b>	<b>15</b>
<b>8.2</b>	<b>UGP service clusters and associated services .....</b>	<b>15</b>
<b>9</b>	<b>UGP service cluster 1 -- Global services .....</b>	<b>16</b>
<b>9.1</b>	<b>GlobalPositiveReply .....</b>	<b>16</b>
<b>9.2</b>	<b>GlobalNegativeReply .....</b>	<b>16</b>
<b>9.3</b>	<b>StopService .....</b>	<b>17</b>
<b>9.3.1</b>	<b>Service description .....</b>	<b>17</b>
<b>9.3.2</b>	<b>Message `StopServiceCall' .....</b>	<b>17</b>
<b>9.3.3</b>	<b>Positive reply .....</b>	<b>17</b>
<b>9.3.4</b>	<b>Error handling .....</b>	<b>17</b>
<b>9.3.5</b>	<b>Example .....</b>	<b>17</b>
<b>9.4</b>	<b>Reset .....</b>	<b>18</b>

9.4.1	Service description .....	18
9.4.2	Message `ResetCall' .....	18
9.4.3	Positive reply .....	18
9.4.4	Error handling .....	18
9.4.5	Example .....	18
10	UGP service cluster 2 -- Authentication .....	19
10.1	Authentication .....	19
10.1.1	Service description .....	19
10.1.2	Message `AuthenticationCall' .....	19
10.1.3	Message `AuthenticationReply' .....	19
10.1.4	Error handling .....	20
10.1.5	Example .....	20
11	UGP service cluster 3 -- Supported data .....	21
11.1	GetSupportedData .....	21
11.1.1	Service description .....	21
11.1.2	Message `GetSupportedDataCall' .....	21
11.1.3	Message `GetSupportedDataReply' .....	22
11.1.4	Error handling .....	23
11.1.5	Example without ECU data .....	23
11.1.6	Example with ECU data .....	24
11.1.7	ECU filtered example .....	25
11.1.8	Negative access type and data parameter property filtered example .....	26
12	UGP service cluster 4 -- Data parameter access .....	26
12.1	GetValue .....	26
12.1.1	Service description .....	26
12.1.2	Message `GetValueCall' .....	26
12.1.3	Message `GetValueReply' .....	27
12.1.4	Error handling .....	28
12.1.5	Single get data parameter list example .....	28
12.1.6	Asynchronous conditioned example .....	29
12.1.7	Monitor example .....	30
12.1.8	Structure example `vehicle info' .....	31
12.2	SetValue .....	32
12.2.1	Service description .....	32
12.2.2	Message `SetValueCall' .....	32
12.2.3	Positive reply .....	33
12.2.4	Error handling .....	33
12.2.5	Example .....	33
12.3	ControlValue .....	34
12.3.1	Service description .....	34
12.3.2	Message `ControlValueCall' .....	34
12.3.3	Message `ControlValueReply' .....	34
12.3.4	Error handling .....	35
12.3.5	Example 1 .....	35
12.3.6	Example 2 .....	38
13	UGP service cluster 5 -- Diagnostic trouble code information access .....	39
13.1	GetDtclInfo .....	39
13.1.1	Service description .....	39
13.1.2	Message `GetDtclInfoCall' .....	39
13.1.3	Message `GetDtclInfoReply' .....	40
13.1.4	Error handling .....	41
13.1.5	Examples .....	41
13.2	ClearDtclInfo .....	42
13.2.1	Service description .....	42
13.2.2	Message `ClearDtclInfoCall' .....	42
13.2.3	Positive reply .....	42
13.2.4	Error handling .....	42

13.2.5	Example .....	42
14	UGP service cluster 6 -- In-vehicle network access .....	43
14.1	EnablePassThru .....	43
14.1.1	Service description .....	43
14.1.2	Message `EnablePassThruCall' .....	43
14.1.3	Positive reply .....	44
14.1.4	Error handling .....	44
14.1.5	Example .....	44
15	UGP service cluster 7 -- Maintenance .....	45
15.1	ListFile .....	45
15.1.1	Service description .....	45
15.1.2	Message `ListFileCall' .....	45
15.1.3	Message `ListFileReply' .....	46
15.1.4	Error handling .....	46
15.1.5	Example .....	46
15.2	ManageFile .....	47
15.2.1	Service description .....	47
15.2.2	Message `ManageFileCall' .....	47
15.2.3	Message `ManageFileReply' .....	48
15.2.4	Error handling .....	48
15.2.5	Example download .....	48
15.2.6	Example upload .....	49
15.2.7	Example delete .....	50
Annex A (normative) Vehicle Interface Data Format definition (VIDF) .....		51
Annex B (normative) Unified gateway protocol ASN.1 definition .....		70
Bibliography .....		78