

ISO 24102-6:2018 (E)

Intelligent transport systems — Communications access for land mobiles (CALM) — ITS station management — Part 6: Path and flow management

Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Symbols and abbreviated terms
5	Overview
5.1	Relation with the ITS station reference architecture
5.2	ITS-S flows
5.3	ITS-S communication profiles
5.4	ITS-S paths
5.5	ITS-S capabilities
5.6	Path and flow management
5.7	ITS station management functionalities
5.8	ITS station management information tables
5.9	Interaction with ITS station layers
6	Requirements for flow management and communication profile selection
6.1	ITS-S flow type parameters
6.2	ITS-S flow parameters
6.3	ITS-S flow monitoring
6.4	Notification of a communication profile determination
6.5	Processing request to provide communication profiles
6.6	Processing flow statistic reports
7	Requirements for flow registration
7.1	Processing ITS-S flow type registration from ITS-S-AP
7.2	Processing RegisterFlow from ITS-S-AP
7.3	Processing ReleaseFlow request from ITS-S-AP
7.4	Checking ITS-S-AP credentials
7.5	Checking communication requirements
7.6	Checking ITS-S path availability
7.7	Communication profile determination
8	Requirements for path management
8.1	ITS-S path parameters
8.2	Topological and geographic position parameters
8.3	Collecting topological and geographical information
8.4	Path management
8.5	ITS-S path monitoring
8.6	Interface management
9	Requirements for path selection
9.1	General requirements for path selection
9.2	Routing policies parameters
9.3	Notifying path selection
9.4	Notifying routing policies

- 10 Requirements for ITS-S capabilities management
 - 10.1 Maintenance of ITS-S capabilities information
 - 10.2 Determination of internal ITS-S capabilities
 - 10.3 Determination of neighbour ITS-S capabilities
 - 10.4 Activating ITS-S capabilities in the ITS-S Managed Service Entity
 - 10.5 Suspending ITS-S capabilities in the ITS-S Managed Service Entity
 - 10.6 Resuming ITS-S capabilities in the ITS-S Managed Service Entity
 - 10.7 Reporting about ITS-S capabilities in the ITS-S Managed Service Entity

Annex A (normative) M*-COMMANDs from SME

- A.1 General
- A.2 Overview
- A.3 Details
 - A.3.1 AdjustFlows
 - A.3.2 CollectFlowStats
 - A.3.3 CollectPathStats
 - A.3.4 DiscoverCapa
 - A.3.5 GetCapa
 - A.3.6 SetCapa
 - A.3.7 SetCP
 - A.3.8 SetFlow2Path
 - A.3.9 SetFlowPolicy
 - A.3.10 SetPath

Annex B (normative) M*-REQUESTs to the SME

- B.1 General
- B.2 Overview
- B.3 Details
 - B.3.1 GetCP
 - B.3.2 NotifyCapa
 - B.3.3 NotifyLocGeo
 - B.3.4 NotifyLocTopo
 - B.3.5 NotifyNeighbourCapa
 - B.3.6 NotifyPath
 - B.3.7 RegisterFlow
 - B.3.8 ReleaseFlow
 - B.3.9 ReportFlowStats
 - B.3.10 ReportPathStats

Annex C (normative) PFM error codes

Annex D (normative) ASN-1 modules

- D.1 Overview
- D.2 Module ITSpfm
- D.3 Dynamic extensions
 - D.3.1 M*-SAP extensions of ISO 24102-3
 - D.3.2 ASN.1 CLASS types of ISO 24102-6
 - D.3.3 Other ASN.1 types