

ISO 13185-4:2020-05 (E)

Intelligent transport systems - Vehicle interface for provisioning and support of ITS Services - Part 4: Unified vehicle interface protocol (UVIP) conformance test specification

Contents		Page
Foreword		viii
Introduction		ix
1	Scope	1
2	Normative references	1
3	Terms, definitions and abbreviated terms	1
3.1	Terms and definitions	1
3.2	Abbreviated terms	1
4	Conventions	2
5	Conformance test plan (CTP) basic principles and clustering	2
5.1	Basic principles for CTC definition	2
5.2	CTC structure	3
5.2.1	CTC - General structure	3
5.2.2	Result criteria	4
5.3	CTC system setup	4
5.4	CTC clustering	5
5.4.1	General	5
5.4.2	Main CTC clusters	5
6	CT cluster 1 - Requesting V-ITS-SG and vehicle identification related information	6
6.1	CTC_UC 1.1 - Browsing available V-ITS-SGs	6
6.1.1	Overview	6
6.1.2	Test purpose	6
6.1.3	Configuration	7
6.1.4	Preamble (setup state)	7
6.1.5	Test execution	7
6.1.6	Postamble (setup state)	8
6.2	CTC_UC 1.2 - Browsing supported ECUs	8
6.2.1	Overview	8
6.2.2	Test purpose	8
6.2.3	Configuration	9
6.2.4	Preamble (setup state)	9
6.2.5	Test execution	9
6.2.6	Postamble (setup state)	9
6.3	CTC_UC 1.3 - Browsing supported data Ids	9
6.3.1	Overview	9
6.3.2	Test purpose	9
6.3.3	Configuration	9
6.3.4	Preamble (setup state)	10
6.3.5	Test execution	10
6.3.6	Postamble (setup state)	10
7	CT cluster 2 - Requesting vehicle and ECU data values	10
7.1	CTC_UC 2.1 - Requesting data ID values for single usage	10

7.1.1	Overview	10
7.1.2	Test purpose	10
7.1.3	Configuration	10
7.1.4	Preamble (setup state)	11
7.1.5	Test execution	11
7.1.6	Postamble (setup state)	11
7.2	CTC_UC 2.2 - Requesting data ID values for repeated usage	12
7.2.1	Overview	12
7.2.2	Test purpose	12
7.2.3	Configuration	12
7.2.4	Preamble (setup state)	12
7.2.5	Test execution	12
7.2.6	Postamble (setup state)	13
7.3	CTC_UC 2.3 - Requesting data ID text and data type information	13
7.3.1	Overview	13
7.4	CTC_UC 2.4 - Requesting data type definitions	13
7.4.1	Overview	13
7.5	CTC_UC 2.5 - Requesting all available text and data type information	13
7.5.1	Overview	13
8	CT cluster 3 - Requesting and clearing DTCs and related data	13
8.1	CTC_UC 3.1 - Requesting DTCs	13
8.1.1	Overview	13
8.1.2	Test purpose	13
8.1.3	Configuration	14
8.1.4	Preamble (setup state)	14
8.1.5	Test execution	14
8.1.6	Postamble (setup state)	14
8.2	CTC_UC 3.2 - Requesting additional DTC data	14
8.2.1	Overview	14
8.2.2	Test purpose	14
8.2.3	Configuration	15
8.2.4	Preamble (setup state)	15
8.2.5	Test execution	15
8.2.6	Postamble (setup state)	15
8.3	CTC_UC 3.3 - Clearing DTCs	15
8.3.1	Overview	15
8.3.2	Test purpose	15
8.3.3	Configuration	16
8.3.4	Preamble (setup state)	16
8.3.5	Test execution	16
8.3.6	Postamble (setup state)	16
8.4	CTC_UC 3.4 - SendOnChange - Provide DTC and status	17
8.4.1	Overview	17
9	CT cluster 4 - Unsolicited V-ITS-SG messages	17
9.1	CTC_UC 4.1 - SendOnEvent -- Emergency situation	17
9.1.1	Overview	17
9.2	CTC_UC 4.2 - SendOnEvent -- Critical driving situation	17
9.2.1	Overview	17
9.3	CTC_UC 4.3 - SendOnEvent -- Safety situation	17
9.3.1	Overview	17
9.4	CTC_UC 4.4 - SendOnEvent -- Warning situation	17
9.4.1	Overview	17
9.5	CTC_UC 4.5 - SendOnEvent -- Data ID value matches threshold	18
9.5.1	Overview	18
10	CT cluster 5 - Real-time data transmission	18
10.1	CTC_UC 5.1 - Real-time data ID value measurement	18
10.1.1	Overview	18
10.2	CTC_UC 5.2 - Real-time DTC reporting	18

10.2.1	Overview	18
11	CT cluster 6 - Controlling /adjusting various equipment of the vehicle	18
11.1	CTC_UC 6.1 - Learn settings of customer profile	18
11.1.1	Overview	18
11.1.2	Test purpose	19
11.1.3	Configuration	19
11.1.4	Preamble (setup state)	19
11.1.5	Test execution	19
11.1.6	Postamble (setup state)	20
11.2	CTC_UC 6.2 - Control convenience system	20
11.2.1	Overview	20
11.2.2	Test purpose	20
11.2.3	Configuration	20
11.2.4	Preamble (setup state)	20
11.2.5	Test execution	20
11.2.6	Postamble (setup state)	21
11.3	CTC_UC 6.3 - Control charging for EV	21
11.3.1	Overview	21
11.3.2	Test purpose	21
11.3.3	Configuration	21
11.3.4	Preamble (setup state)	21
11.3.5	Test execution	22
11.3.6	Postamble (setup state)	22
12	CT cluster 7 - Writing short- and long-term data to V-ITS-SG	22
12.1	CTC_UC 7.1 - Write data to V-ITS-SG's memory	22
12.1.1	Overview	22
12.1.2	Test purpose	22
12.1.3	Configuration	23
12.1.4	Preamble (setup state)	23
12.1.5	Test execution	23
12.1.6	Postamble (setup state)	23
12.2	CTC_UC 7.2 - Write vehicle profile to V-ITS-SG's memory	23
12.2.1	Overview	23
12.3	CTC_UC 7.3 - Enable/disable functional system related data IDs	24
12.3.1	Overview	24
12.4	CTC_UC 7.4 - Write data ID thresholds to V-ITS-SG's memory	24
12.4.1	Overview	24
13	CT cluster 8 - V-ITS-SG accessibility restrictions and firewall protection cluster	24
13.1	CTC_UC 8.1 - Secure access to V-ITS-SG	24
13.1.1	Overview	24
13.1.2	Test purpose	24
13.1.3	Configuration	24
13.1.4	Preamble (setup state)	24
13.1.5	Test execution	24
13.1.6	Postamble (setup state)	25
13.2	CTC_UC 8.2 - Request V-ITS-SG firewall status	25
13.2.1	Overview	25
13.3	CTC_UC 8.3 - Configuration of V-ITS-SG firewall	25
13.3.1	Overview	25
13.3.2	Test purpose	25
13.3.3	Configuration	25
13.3.4	Preamble (setup state)	26
13.3.5	Test execution	26
13.3.6	Postamble (setup state)	26
14	CT cluster 9 - V-ITS-SG special features	26
14.1	CTC_UC 9.1 - General data exchange	26
14.1.1	Overview	26
14.2	CTC_UC 9.2 - V-ITS-SG activation mode	27

14.2.1	Overview	27
14.3	CTC_UC 9.3 - Upload EventLogFile from V-ITS-SG	27
14.3.1	Overview	27
14.3.2	Test purpose	27
14.3.3	Configuration	27
14.3.4	Preamble (setup state)	27
14.3.5	Test execution	27
14.3.6	Postamble (setup state)	28
15	CT cluster 10 - Vehicle diagnostics	28
15.1	CTC_UC 10.1 - Perform functional group OBD	28
15.1.1	Overview	28
15.1.2	Test purpose	28
15.1.3	Configuration	28
15.1.4	Preamble (setup state)	28
15.1.5	Test execution	28
15.1.6	Postamble (setup state)	29
15.2	CTC_UC 10.2 - Perform enhanced OBD	29
15.2.1	Overview	29
15.2.2	Test purpose	29
15.2.3	Configuration	29
15.2.4	Preamble (setup state)	29
15.2.5	Test execution	29
15.2.6	Postamble (setup state)	30
15.3	CTC_UC 10.3 - Upload VSOCLogFile from V-ITS-SG	30
15.3.1	Overview	30
15.3.2	Test purpose	30
15.3.3	Configuration	30
15.3.4	Preamble (setup state)	30
15.3.5	Test execution	30
15.3.6	Postamble (setup state)	31
16	CT cluster 11 - Electric vehicle system status	31
16.1	CTC_UC 11.1 - Monitor battery charge status	31
16.1.1	Overview	31
16.1.2	Test purpose	31
16.1.3	Configuration	31
16.1.4	Preamble (setup state)	31
16.1.5	Test execution	31
16.1.6	Postamble (setup state)	32
16.2	CTC_UC 11.2 - Monitor connection between charging station and EV	32
16.2.1	Overview	32
16.2.2	Test purpose	32
16.2.3	Configuration	32
16.2.4	Preamble (setup state)	32
16.2.5	Test execution	32
16.2.6	Postamble (setup state)	33
16.3	CTC_UC 11.3 - Battery charge start/stop notification	33
16.3.1	Overview	33
17	CT cluster 12 - V-ITS-SG maintenance	33
17.1	CTC_UC 12.1 - Update core software of V-ITS-SG	33
17.1.1	Overview	33
17.1.2	Test purpose	33
17.1.3	Configuration	34
17.1.4	Preamble (setup state)	34
17.1.5	Test execution	34
17.1.6	Postamble (setup state)	34
17.2	CTC_UC 12.2 - Perform a Reset in V-ITS-SG	34
17.2.1	Overview	34
17.2.2	Test purpose	34
17.2.3	Configuration	35

17.2.4	Preamble (setup state)	35
17.2.5	Test execution	35
17.2.6	Postamble (setup state)	35
17.3	CTC_UC 12.3 - Perform a reset in V-ITS-SG	35
17.3.1	Overview	35
17.3.2	Test purpose	35
17.3.3	Configuration	35
17.3.4	Preamble (setup state)	35
17.3.5	Test execution	36
17.3.6	Postamble (setup state)	36
17.4	CTC_UC 12.4 - Upload V-ITS-SG configuration file	36
17.4.1	Overview	36
17.4.2	Test purpose	36
17.4.3	Configuration	36
17.4.4	Preamble (setup state)	36
17.4.5	Test execution	36
17.4.6	Postamble (setup state)	37
17.5	CTC_UC 12.5 - Download V-ITS-SG configuration file	37
17.5.1	Overview	37
17.5.2	Test purpose	37
17.5.3	Configuration	37
17.5.4	Preamble (setup state)	37
17.5.5	Test execution	37
17.5.6	Postamble (setup state)	38
Bibliography		39