

DIN EN 15423:2008-09 (E)

Ventilation for buildings - Fire precautions for air distribution systems in buildings

| Contents | | Page |
|---|--|-------------|
| Foreword | | 3 |
| 1 | Scope | 4 |
| 2 | Normative references | 5 |
| 3 | Terms and definitions | 6 |
| 4 | Air distribution system | 7 |
| 4.1 | General requirements | 7 |
| 4.2 | Design of air distribution systems | 7 |
| 4.3 | Installation | 7 |
| 5 | Requirements for components intended for fire precautions | 7 |
| 5.1 | General | 7 |
| 5.2 | Inlet/outlet louvres | 8 |
| 5.3 | Fans | 8 |
| 5.4 | Air control dampers | 10 |
| 5.5 | Duct | 11 |
| 5.6 | Fire dampers and smoke control dampers | 11 |
| 5.7 | Air terminal devices | 12 |
| 5.8 | Anchors and supports | 13 |
| 5.9 | Duct fittings | 13 |
| 5.10 | Control panels | 13 |
| 5.11 | Cables and connections | 14 |
| 5.12 | Air handling units | 14 |
| 5.13 | Air filters | 15 |
| 5.14 | Sound attenuators | 16 |
| 5.15 | Heat exchangers | 16 |
| 6 | Commissioning and maintenance of air distribution systems | 16 |
| 7 | Marking, labelling and product information | 17 |
| Bibliography | | 24 |
| Annex A (informative) Checklist for components | | 18 |
| Annex B (informative) Table of components/characteristics European Standards | | 20 |
| Annex C (informative) Maintenance for fire dampers and smoke control dampers | | 22 |