

# ISO/TS 14934-4:2007-02 (E)

## Fire tests - Calibration of heat flux meters - Part 4: Guidance on the use of heat flux meters in fire tests

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
1	Scope .....	1
2	Normative references .....	1
3	Terms and definitions .....	1
4	General information on heat flux meters .....	1
4.1	General .....	1
4.2	Principle of measurement .....	2
4.3	Design of heat flux meter .....	3
4.4	Measurement characteristics .....	5
4.5	Physical shape of heat flux meter .....	7
5	Attachments to heat flux meters .....	8
5.1	Air purging .....	8
5.2	Windows .....	9
5.3	Cooling system .....	10
6	Selection of a suitable heat flux meter .....	12
6.1	General .....	12
6.2	Range of measurement .....	12
6.3	Type, dimensions and orientation .....	13
6.4	View angle .....	13
6.5	Response time .....	13
6.6	Sensitivity to convective heat transfer .....	13
7	Performing a measurement .....	14
7.1	Installation .....	14
7.2	Target surface .....	15
7.3	Electronics .....	15
7.4	Relationship between output voltage and total heat flux .....	15
8	Calibration .....	16
8.1	Secondary standard heat flux meter .....	16
8.2	Working standard heat flux meters .....	16
8.3	Frequency of calibration .....	16
9	Maintenance .....	17
9.1	Absorber .....	17
9.2	Wiring .....	17
9.3	Water supply .....	17
10	Use of heat flux meters in fire tests .....	17
10.1	General .....	17
10.2	Ignitability test (see ISO 5657) .....	17
10.3	Spread of flame test (see ISO 5658, all parts) .....	17
10.4	Heat release, smoke production and mass loss (see ISO 5658, all parts, and ISO 17554) ..	18

<b>10.5</b>	<b>Full-scale room test for surface products (see ISO 9705)</b> .....	<b>18</b>
<b>10.6</b>	<b>Façade tests (see ISO 13785-2)</b> .....	<b>18</b>
<b>10.7</b>	<b>Spread of flame test for floor coverings (see ISO 9239, all parts)</b> .....	<b>18</b>
<b>10.8</b>	<b>Intermediate-scale heat-release calorimeter (ICAL) (see ISO/TR 14696)</b> .....	<b>18</b>
	<b>Bibliography</b> .....	<b>19</b>