

# ISO 11783-5:2011-04 (E)

## Tractors and machinery for agriculture and forestry - Serial control and communications data network - Part 5: Network management

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
Introduction .....		v
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions .....</b>	<b>2</b>
<b>4</b>	<b>Technical requirements .....</b>	<b>2</b>
4.1	General .....	2
4.2	Address configuration capabilities .....	3
4.2.1	General .....	3
4.2.2	Non-configurable address .....	3
4.2.3	Self-configurable address .....	3
4.2.4	Service-configurable address .....	3
4.2.5	Command-configurable address .....	3
4.3	NAME and address requirements .....	4
4.3.1	General .....	4
4.3.2	NAME .....	4
4.3.3	Address .....	6
4.4	Network-management procedure .....	7
4.4.1	General .....	7
4.4.2	Address-management messages and procedures .....	8
4.4.3	NAME management message and procedures .....	10
4.4.4	Network-error management .....	19
4.5	Network initialization .....	19
4.5.1	Acquisition of a unique address .....	19
4.5.2	Address claim requirements .....	20
4.5.3	Other basic requirements for initialization .....	20
4.5.4	Message sequences .....	21
4.5.5	CF unable to obtain an address .....	25
4.6	Physical requirements .....	26
4.6.1	Reaction to power-supply voltage disturbances .....	26
4.6.2	Network disruption during connection, disconnection or power-up .....	26
Annex A (informative) Examples of NAME construction .....		27
Bibliography .....		29