

# ISO 4302:2016-10 (E)

## Cranes - Wind load assessment

---

<b>Contents</b>		<b>Page</b>
Foreword .....		iv
<b>1</b>	<b>Scope .....</b>	<b>1</b>
<b>2</b>	<b>Normative references .....</b>	<b>1</b>
<b>3</b>	<b>Terms, definitions, symbols and abbreviated terms .....</b>	<b>1</b>
<b>4</b>	<b>Wind pressure .....</b>	<b>2</b>
<b>5</b>	<b>In-service wind .....</b>	<b>3</b>
<b>5.1</b>	<b>General .....</b>	<b>3</b>
<b>5.2</b>	<b>Action of in-service wind on suspended load .....</b>	<b>3</b>
<b>5.3</b>	<b>Wind load calculations .....</b>	<b>4</b>
<b>5.4</b>	<b>Shape coefficients for individual members, frames, etc .....</b>	<b>4</b>
<b>5.5</b>	<b>Shielding factors -- Multiple frames or members .....</b>	<b>5</b>
<b>5.6</b>	<b>Wind loads on individual members (inclined to the wind direction) .....</b>	<b>7</b>
<b>6</b>	<b>Out-of-service wind .....</b>	<b>7</b>
<b>6.1</b>	<b>General .....</b>	<b>7</b>
<b>6.2</b>	<b>Loads due to out-of-service wind .....</b>	<b>8</b>
<b>6.3</b>	<b>Equivalent static out-of-service wind pressure .....</b>	<b>8</b>
<b>6.4</b>	<b>Wind loads on individual members (inclined to the wind direction) .....</b>	<b>9</b>
<b>6.5</b>	<b>Storm wind maps .....</b>	<b>9</b>
<b>Annex A (informative) Reference storm wind speeds .....</b>		<b>11</b>
<b>Bibliography .....</b>		<b>22</b>