

DIN EN 528:2023-02 (E)

Rail dependent storage and retrieval equipment - Safety requirements for S/R machines (includes Amendment :2022)

Contents		Page
European foreword.....		5
Introduction.....		7
1 Scope		8
2 Normative references		8
3 Terms and definitions.....		10
4 Safety requirements and/or protective/risk reduction measures.....		13
4.1 General.....		13
4.2 Control position		13
4.2.1 General.....		13
4.2.2 Access to and egress from the permanent on-board control position.....		13
4.2.3 Floor of the on-board control position		13
4.2.4 Design and dimensioning of permanent on-board control position		13
4.2.5 Emergency call device on permanent on-board control positions		14
4.2.6 Lighting on permanent on-board control position		14
4.3 Control equipment.....		15
4.3.1 General.....		15
4.3.2 Safeguard of the operator on a permanent on-board control position		15
4.3.3 Prevention of unauthorised operation (equipment switch)		15
4.3.4 Changing mode of operation (mode switch)		15
4.3.5 Key dependence.....		16
4.3.6 Control devices for powered movements.....		16
4.3.7 Control device identification.....		16
4.3.8 Stop function		16
4.3.9 Emergency stop function		17
4.3.10 Safety requirements related to EMC.....		17
4.4 Hoist unit.....		17
4.4.1 Hoist unit brake		17
4.4.2 Limitation of the lifting and lowering movement.....		18
4.4.3 Overload and slack condition protection		18
4.4.4 Safety gear and overspeed governor		19
4.4.5 Suspension elements.....		20
4.4.6 Hydraulic drives		23
4.4.7 Lead-screw drive		23
4.4.8 Rack and pinion drives.....		24
4.5 Travel unit of the S/R machine.....		24
4.5.1 Travel unit braking system.....		24
4.5.2 Speed reducing system.....		25
4.5.3 Limitation of travel.....		25
4.5.4 Anti-derailment devices.....		26
4.5.5 Stability		26
4.6 Load handling devices		27
4.6.1 Load stability.....		27
4.6.2 Determination of possible impacts on the rack		27
4.6.3 Rotating devices.....		27
4.6.4 Interlocking functions		27
4.6.5 Auxiliary handling equipment.....		27
4.6.6 Load position monitoring.....		28

4.6.7	Satellites	28
4.7	Electrical equipment	28
4.7.1	General	28
4.7.2	Electrical supply conditions	28
4.7.3	Environment	28
4.7.4	Supply disconnecting (isolating) device	28
4.7.5	Protection against electric shock	29
4.7.6	Suspension of safeguarding	29
4.7.7	Overriding of safety functions	29
4.8	Transfer device	29
4.8.1	General	29
4.8.2	Retention of position	30
4.8.3	Movement	30
4.8.4	Interlocking functions	30
4.8.5	Stability	30
4.9	Maintenance repair and fault clearance	30
4.9.1	General	30
4.9.2	Maintenance position	30
4.9.3	Emergency control position	31
4.9.4	Speed limitation	31
4.9.5	Communication	32
4.9.6	Protection from operating machines (S/R machines and its transfer equipment)	32
4.9.7	Access along the mast	32
4.10	Machine environment	34
4.10.1	General	34
4.10.2	Communication of force information	34
4.10.3	Safety clearances	34
4.10.4	Safeguarding of persons (Limiting access)	34
4.10.5	Load entry / exit points	35
4.10.6	Escape from dangerous areas	36
4.10.7	Protection against unintentional load movement	37
4.10.8	Protection against falling	38
5	Verification of safety requirements and/or measures	38
5.1	Examination	38
5.1.1	General	38
5.1.2	Movements to be done	38
5.1.3	Test of the safety gear	38
5.1.4	Verification of the mechanical limits of travel	39
5.1.5	Test of the lowering control valve	39
5.1.6	Written record	39
5.2	EMC	39
5.3	Noise	39
5.3.1	General	39
5.3.2	Noise measurement	39
5.3.3	Declaration	40
5.4	Load tests	41
5.4.1	Test load	41
5.4.2	Static load test	41
5.4.3	Dynamic load test	41
5.4.4	Load test record	41
6	Information for use	41
6.1	General	41
6.2	Erection on site	41
6.3	Commissioning	41
6.3.1	Method statement	41

- 6.3.2 Instructions 42
- 6.3.3 Training 42
- 6.3.4 Safety devices..... 42
- 6.3.5 Individual elements of the machine 42
- 6.3.6 Integrated commissioning 42
- 6.4 Normal operation 42
- 6.4.1 General..... 42
- 6.4.2 Operation and use 42
- 6.4.3 Maintenance, repair and fault-clearing..... 42
- 6.4.4 Spare parts..... 42
- 6.4.5 Certification of suspension elements..... 42
- 6.4.6 Noise declaration..... 42
- 6.4.7 Test report 43
- 6.4.8 Minimum markings 43
- 6.4.9 Conditions for the safe operation of equipment 43
- 6.5 Fault finding/troubleshooting..... 46
- 6.5.1 General 46
- 6.5.2 Description of safe access and egress to trouble points on the S/R machine..... 46
- 6.5.3 Description of safe access and egress to trouble points at the interface between S/R machine and racking..... 46
- 6.5.4 Description of safe access and egress to trouble points at the interface between the S/R machine and the conveying system..... 46
- 6.5.5 Training 46
- 6.6 Rescue of persons..... 46
- 6.7 Maintenance, inspection, testing and training 46
- 6.7.1 General 46
- 6.7.2 Maintenance 46
- 6.7.3 Periodic maintenance and testing..... 47
- 6.7.4 Training 48
- 6.8 Dismantling 48
- Annex A (informative) Figures..... 49
- Annex B (normative) Performance levels according to EN ISO 13849-1:2015 57
- Annex C (normative) Preventing access to dangerous movements across the load entry/exit points 64
- Annex D (normative) Access to restricted areas..... 76
- Annex E (normative) Verification of safety requirements and/or measures 79
- Annex F (normative) List of significant and relevant hazards..... 86
- Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 2006/42/EU aimed to be covered..... 91
- Bibliography 99