

# ISO 23316-4:2023-08 (E)

## Tractors and machinery for agriculture and forestry - Electrical high-power interface 700 V DC / 480 V AC - Part 4: AC operation mode

---

<b>Contents</b>		<b>Page</b>
<b>Foreword</b>		<b>iv</b>
<b>Introduction</b>		<b>v</b>
<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Normative references</b>	<b>1</b>
<b>3</b>	<b>Terms and definitions</b>	<b>2</b>
<b>4</b>	<b>AC System overview</b>	<b>4</b>
4.1	Basic AC system topology	4
4.2	Load configurations	6
4.3	Consumer system configuration	7
4.3.1	Operation with single consumer system	7
4.3.2	Operation with multiple consumer systems	7
4.4	Control modes	8
4.4.1	Closed-loop control modes	8
4.4.2	Open-loop control modes	9
4.5	AC voltage and current	9
4.5.1	AC voltage	9
4.5.2	AC current	11
4.6	Cable length	11
4.7	Basic control modes	11
4.7.1	General	11
4.7.2	Closed-loop control modes	13
4.7.3	Open-loop control modes	15
4.8	Interlock	17
4.8.1	General	17
4.8.2	Interlock function — Closed loop AC modes	17
4.8.3	Interlock function — Open loop AC modes	17
4.8.4	Interlock function — DC supply with AC HPI	17
<b>5</b>	<b>EtherCAT</b>	<b>18</b>
5.1	Background	18
5.2	Physical layer	18
5.3	Initialization data	18
5.4	Cyclic control feedback data	18
	<b>Bibliography</b>	<b>19</b>