

ISO 13649:2024-09 (E)

Earth-moving machinery - Fire prevention guidance

| Contents | | Page |
|--|--|-------------|
| Foreword | | iv |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | Fire hazards | 2 |
| 4.1 | General | 2 |
| 4.2 | Fuel sources | 3 |
| 4.2.1 | General | 3 |
| 4.2.2 | Machine components | 3 |
| 4.2.3 | Machine fluids, gases and other onboard substances | 3 |
| 4.2.4 | Environmental debris | 3 |
| 4.3 | Oxidizers | 3 |
| 4.4 | Ignition sources | 3 |
| 4.4.1 | General | 3 |
| 4.4.2 | Thermal energy ignition sources | 4 |
| 4.4.3 | Electrical energy ignition sources | 4 |
| 4.4.4 | Mechanical energy ignition sources | 4 |
| 5 | Strategy for risk assessment and risk reduction | 4 |
| 6 | Design guidance for fire risk reduction | 5 |
| 6.1 | General | 5 |
| 6.2 | Ignition sources | 5 |
| 6.2.1 | Mechanical and thermal ignition sources | 5 |
| 6.2.2 | Electrical ignition sources | 5 |
| 6.3 | Fuel sources | 6 |
| 6.4 | Segregation of fuel and ignition sources | 7 |
| 6.5 | Fire extinguishers and fire suppression | 8 |
| 7 | Information for use | 8 |
| 7.1 | General | 8 |
| 7.2 | Fire prevention | 8 |
| 7.2.1 | Operation | 8 |
| 7.2.2 | Fuelling | 9 |
| 7.2.3 | Starting | 9 |
| 7.2.4 | Maintenance and inspection | 9 |
| 7.2.5 | Service and repair | 11 |
| 7.3 | Fire safety | 11 |
| Annex A (informative) Examples of fuel sources | | 13 |
| Annex B (informative) Examples of ignition sources | | 15 |
| Bibliography | | 17 |