

# DIN EN 14983:2007-06 (E)

## Explosion prevention and protection in underground mines - Equipment and protective systems for firedamp drainage

---

Contents	Page
Foreword .....	4
Introduction .....	5
1 Scope .....	6
2 Normative references .....	6
3 Terms and definitions .....	6
4 Equipment and protective systems for firedamp drainage .....	8
4.1 General .....	8
4.2 Borehole standpipes .....	8
4.3 Drainage pipes for seals and stoppings .....	12
4.4 Water separators at drainage points .....	12
4.5 Firedamp pipes .....	12
4.5.1 General requirements for firedamp pipes .....	12
4.5.2 Measuring points for measuring equipment in firedamp drainage pipes .....	13
4.6 Pressure vessels in firedamp drainage plant .....	13
4.7 Exhausters .....	13
4.7.1 Requirements for exhausters .....	13
4.7.2 Reserve exhausters .....	14
4.7.3 Location of exhausters .....	14
4.8 Venting of the drained firedamp .....	14
4.9 Explosion prevention systems for pipelines .....	15
4.9.1 Explosion barriers .....	15
4.9.2 Non-flammable firedamp vent pipe outlets and flame arrester outlets .....	15
4.9.3 Reserve container and operating state .....	16
4.10 Requirements for the design of electrical safety devices .....	16
4.11 Electrostatic ignition risks .....	16
5 Instructions for installation and use .....	17
Annex A (informative) Installation and use of firedamp drainage system .....	18
A.1 General .....	18
A.2 Work on firedamp pipes .....	18
A.3 Measures to be taken when gas levels fall below or exceed limit values during firedamp drainage .....	19
A.4 Failure or shutdown of exhausters .....	19
Annex B (informative) Monitoring of firedamp drainage system .....	20
B.1 Examination and inspection by competent persons .....	20
B.2 Measurement of the drained firedamp mixture and pressure .....	20
B.2.1 Measurements taken by hand .....	20
B.2.2 Fixed monitoring equipment .....	20
B.3 Documentation .....	21
B.4 Firedamp circuit plan .....	21
Annex C (informative) Requirements for location of exhausters .....	22

<b>Annex D (informative) Requirements for gas removal equipment for abandoned surface outlets .....</b>	<b>23</b>
<b>Annex E (informative) Example for calculation of t90 path .....</b>	<b>27</b>
E.1 <b>General .....</b>	<b>27</b>
E.2 <b>Example for calculation of t90-path .....</b>	<b>27</b>
<b>Annex ZA (informative) Relationship between this European Standard and the Essential Requirements of EU Directive 94/9/EC .....</b>	<b>29</b>
<b>Bibliography .....</b>	<b>31</b>
<b>Figures</b>	
<b>Figure 1 -- Example of connection of roof borehole to collector pipe when measurement and control are accessible .....</b>	<b>9</b>
<b>Figure 2 -- Example of connection of roof borehole to collector pipe when measurement and control are not accessible .....</b>	<b>10</b>
<b>Figure 3 -- Example of connection of floor borehole to collector pipe when measurement and control are accessible .....</b>	<b>11</b>
<b>Figure 4 -- Example of connection of floor borehole to collector pipe when measurement and control are not accessible .....</b>	<b>12</b>
<b>Figure 5 -- Example of explosion prevention system for pipelines with one firedamp vent pipe .....</b>	<b>15</b>
<b>Figure D.1 -- Passive gas removal equipment (Type II) .....</b>	<b>25</b>
<b>Figure D.2 -- Passive gas removal equipment (Type III) .....</b>	<b>26</b>
<b>Figure E.1 -- Schematic arrangement of a t90-path .....</b>	<b>28</b>
<b>Tables</b>	
<b>Table D.1 -- Requirements for gas removal equipment for abandoned surface outlets .....</b>	<b>24</b>
<b>Table ZA.1 -- Correspondence between the European Standard and Directive 94/9/EC .....</b>	<b>29</b>