

# ISO 22017:2020 (E)

## Water quality — Guidance for rapid radioactivity measurements in nuclear or radiological emergency situation

---

### Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Guidance on emergency measurement
4.1	Objective of a specific rapid measurement
4.2	Routine screening levels versus intervention levels
4.3	Operational intervention levels (OILs) from EU, USA and IAEA
5	Rapid measurements
5.1	Adaptation of the methods used
5.2	Sampling
5.3	Rapid test methods
5.3.1	Pre-screening: Identification of most contaminated samples
5.3.2	Selection of the analytical strategy
5.3.3	Appropriate sample volumes and counting times related to intervention levels
5.3.4	Gross-alpha and gross-beta determination and gamma spectrometry
5.3.5	Specific separations for alpha emitters or pure beta emitters measurement
6	Laboratory management to perform rapid measurements
6.1	Protection of laboratory staff
6.2	Sample management
6.3	Material and staff
6.4	Quality management
6.5	Expression of results and test report
Annex A	(informative) World Health Organization screening for radionuclides in drinking water
Annex B	(informative) Operational Intervention Levels (OILs) from EU, US and IAEA
Annex C	(informative) Overview of different types of rapid measurements during a nuclear or radiological emergency
Annex D	(informative) Example of a decision scheme for rapid measurements in the early phase

Page count: 20