ISO 22017:2020 (E)

Water quality — Guidance for rapid radioactivity measurements in nuclear or radiological emergency situation

Contents

Foreword

Introduction

1 Scope

2 Normative references

3 Terms and definitions

4 Guidance on emergency measurement

- 4.1 Objective of a specific rapid measurement
- 4.2 Routine screening levels versus intervention levels
- 4.3 Operational intervention levels (OILs) from EU, USA and IAEA

5 Rapid measurements

- 5.1 Adaptation of the methods used
- 5.2 Sampling
- 5.3 Rapid test methods
- 5.3.1 Pre-screening: Identification of most contaminated samples
- 5.3.2 Selection of the analytical strategy
- 5.3.3 Appropriate sample volumes and counting times related to intervention levels
- 5.3.4 Gross-alpha and gross-beta determination and gamma spectrometry
- 5.3.5 Specific separations for alpha emitters or pure beta emitters measurement

6 Laboratory management to perform rapid measurements

- 6.1 Protection of laboratory staff
- 6.2 Sample management
- 6.3 Material and staff
- 6.4 Quality management
- 6.5 Expression of results and test report

Annex A (informative) World Health Organization screening for radionuclides in drinking water

Annex B (informative) Operational Intervention Levels (OILs) from EU, US and IAEA

Annex C (informative) Overview of different types of rapid measurements during a nuclear or radiological emergency

Annex D (informative) Example of a decision scheme for rapid measurements in the early phase

Page count: 20