

# ISO/IEC 13818-6:1998-09 (E)

## Information technology - Generic coding of moving pictures and associated audio information - Part 6: Extensions for DSM-CC

---

Contents	Page
0. INTRODUCTION .....	xix
0.1 Guiding Factors in the Formulation of DSM-CC .....	xix
0.2 DSM-CC Client-Network-Server Model .....	xx
0.3 Outline of the DSM-CC Specification .....	xx
0.3.1 User-to-Network .....	xx
0.3.2 User-to-User .....	xxi
0.4 Supported Network Technologies .....	xxi
0.5 Supported Connection Types .....	xxi
0.6 DSM-CC Interfaces .....	xxi
0.7 DSM-CC Interface Protocols .....	xxiii
0.8 Communications Requirements .....	xxv
0.9. Methods of Specification .....	xxv
0.9.1 Messages .....	xxv
0.9.2 Message Flow Diagram Scenarios .....	xxvi
0.9.3 Specification and Description Language .....	xxvi
0.9.4 Interface Definition Language (IDL) .....	xxviii
0.9.5 Remote Procedure Call (RPC) .....	xxviii
0.9.5.1 Independence of RPC .....	xxix
0.9.5.2 Preferred and Default RPC .....	xxix
0.9.5.3 Local Equivalent Functions .....	xxix
1. GENERAL .....	1
1.1 Scope .....	1
1.2 Profiles and Compliance .....	1
1.2.1 Functional Categories of the DSM-CC protocols .....	1
1.2.2 User-to-Network Session Messages .....	2
1.2.2.1 U-N Core Session Message Functional Groups .....	2
1.2.2.2 U-N Extended Session Message Functional Groups .....	2
1.2.3 User-User Interfaces .....	2
1.2.3.1 U-U Core Interfaces .....	2
1.2.3.2 U-U Extended Interfaces .....	3
1.3 Definitions .....	3
1.4 Acronyms .....	4
1.5 Normative References .....	6
2. DSM-CC MESSAGE HEADER .....	7
2.1 DSM-CC Adaptation Header Format .....	8
2.1.1 DSM-CC Conditional Access Adaptation Format .....	9
2.1.2 DSM-CC User ID Adaptation Format .....	9
3. USER-TO-NETWORK CONFIGURATION MESSAGES .....	10
3.1 Overview and the General Message Format .....	10
3.2 User-to-Network configuration parameters .....	10
3.2.1 DSM-CC specific configuration parameters .....	10
3.2.2 Network specific configuration parameters 1 .....	1
3.2.3 User defined configuration parameters .....	12
3.3 User to Network Configuration Messages .....	12
3.3.1 UNConfigRequest message definition .....	13
3.3.2 UNConfigConfirm message definition .....	13
3.3.3 UNConfigIndication message definition .....	14
3.3.4 UNConfigResponse message definition .....	14
3.4 User-to-Network Configuration Message Field Data Types .....	15
3.5 User Initiated UNConfigRequest message Sequence .....	15

3.6	Network Initiated UNConfigIndication message Sequence .....	16
3.7	Broadcasting of UNConfigIndication messages .....	16
3.8	Mixed User/Network Initiated Configuration Sequences .....	17
3.9	User-to-Network Configuration Reason Codes .....	17
3.10	User-to-Network Configuration Response Codes .....	17
<b>4.</b>	<b>USER-TO-NETWORK SESSION MESSAGES .....</b>	<b>19</b>
4.1	Overview and the General Message Format .....	19
4.2	Session Messages .....	19
4.2.1	U-N Functional groups .....	23
4.2.1.1	U-N Core Group .....	23
4.2.1.2	Extended Functional groups .....	24
4.2.2	Use of UserData() structure in session messages .....	24
4.2.3	Use of Resources() structure in session messages .....	25
4.2.4	Session Set-Up group message definitions .....	25
4.2.4.1	ClientSessionSetUpRequest .....	25
4.2.4.2	ClientSessionSetUpConfirm .....	26
4.2.4.3	ServerSessionSetUpIndication .....	27
4.2.4.4	ServerSessionSetUpResponse .....	27
4.2.5	Session Release group message definitions .....	28
4.2.5.1	ClientSessionReleaseRequest .....	28
4.2.5.2	ClientSessionReleaseConfirm .....	29
4.2.5.3	ClientSessionReleaseIndication .....	29
4.2.5.4	ClientSessionReleaseResponse .....	29
4.2.5.5	ServerSessionReleaseRequest .....	30
4.2.5.6	ServerSessionReleaseConfirm .....	30
4.2.5.7	ServerSessionReleaseIndication .....	31
4.2.5.8	ServerSessionReleaseResponse .....	31
4.2.6	Add Resource group message definitions .....	32
4.2.6.1	ClientAddResourceIndication .....	32
4.2.6.2	ClientAddResourceResponse .....	32
4.2.6.3	ServerAddResourceRequest .....	33
4.2.6.4	Server AddResourceConfirm .....	33
4.2.7	Delete Resource group message definitions.....	34
4.2.7.1	ClientDeleteResourceIndication.....	34
4.2.7.2	ClientDeleteResourceResponse .....	35
4.2.7.3	ServerDeleteResourceRequest .....	35
4.2.7.4	ServerDeleteResourceConfirm.....	36
4.2.8	Continuous Feed Session group message definitions .....	36
4.2.8.1	ServerContinuousFeedSessionRequest .....	36
4.2.8.2	ServerContinuousFeedSessionConfirm .....	37
4.2.9	Status group message definitions .....	37
4.2.9.1	ClientStatusRequest.....	37
4.2.9.2	ClientStatusConfirm .....	38
4.2.9.3	ClientStatusIndication .....	38
4.2.9.4	ClientStatusResponse.....	38
4.2.9.5	ServerStatusRequest .....	39
4.2.9.6	ServerStatusConfirm .....	39
4.2.9.7	ServerStatusIndication.....	40
4.2.9.8	ServerStatusResponse .....	40
4.2.10	Reset group message definitions .....	41
4.2.10.1	ClientResetRequest.....	41
4.2.10.2	ClientResetConfirm .....	41
4.2.10.3	ClientResetIndication .....	42
4.2.10.4	ClientResetResponse .....	42
4.2.10.5	ServerResetRequest.....	42
4.2.10.6	ServerResetConfirm .....	43
4.2.10.7	ServerResetIndication .....	43
4.2.10.8	ServerResetResponse.....	43
4.2.11	Session Proceeding group message definitions .....	44
4.2.11.1	ClientSessionProceedingIndication .....	44
4.2.11.2	ServerSessionProceedingIndication .....	44

4.2.12	Connect group message definitions .....	44
4.2.12.1	ClientConnectRequest .....	44
4.2.12.2	ServerConnectIndication .....	45
4.2.13	Session Transfer group message definitions .....	45
4.2.13.1	ClientSessionTransferIndication .....	45
4.2.13.2	ClientSessionTransferResponse .....	46
4.2.13.3	ServerSessionTransferRequest .....	46
4.2.13.4	ServerSessionTransferConfirm .....	47
4.2.13.5	ServerSessionTransferIndication .....	47
4.2.13.6	ServerSessionTransferResponse .....	48
4.2.14	Session In Progress group message definitions .....	49
4.2.14.1	ClientSessionInProgress .....	49
4.2.14.2	ServerSessionInProgress .....	49
4.3	User-to-Network Session Message Field Data Types .....	49
4.4	Reason Codes .....	52
4.5	Response Codes .....	53
4.6	MPEG-2 DSM-CC statusTypes .....	55
4.7	Resource Descriptors .....	56
4.7.1	DSM-CC User-to-Network Resource Descriptor .....	56
4.7.2	Specifying Ranges and Lists of values in resource descriptors .....	62
4.7.3	Horizontal Association of Resource Descriptors .....	64
4.7.4	Vertical Resource Sharing .....	64
4.7.5	Resource Descriptor Definitions .....	65
4.7.5.1	ContinuousFeedSession resource descriptor definition .....	66
4.7.5.2	AtmConnection resource descriptor definition .....	67
4.7.5.3	MpegProgram resource descriptor definition .....	67
4.7.5.4	Physical Channel resource descriptor definition .....	68
4.7.5.5	TSUpstreamBandwidth resource descriptor definition .....	69
4.7.5.6	TSDownstreamBandwidth resource descriptor definition .....	69
4.7.5.7	AtmSvcConnection resource descriptor definition .....	70
4.7.5.8	ConnectionNotify resource descriptor definition .....	70
4.7.5.9	IP resource descriptor definition .....	70
4.7.5.10	ClientTdmaAssignment resource descriptor definition .....	71
4.7.5.11	PSTNSetup resource descriptor definition .....	71
4.7.5.12	NISDNSetup resource descriptor definition .....	71
4.7.5.13	NISDNConnection resource descriptor definition .....	72
4.7.5.14	Q922Connections resource descriptor definition .....	72
4.7.5.15	SharedResource resource descriptor definition .....	72
4.7.5.16	SharedRequestId resource descriptor definition .....	72
4.7.5.17	HeadEndList resource descriptor definition .....	73
4.7.5.18	AtmVcConnection resource descriptor definition .....	73
4.7.5.19	SdbContinuousFeed resource descriptor definition .....	74
4.7.5.20	SdbAssociations resource descriptor definition .....	74
4.7.5.21	SdbEntitlement resource descriptor definition .....	75
4.8	Client Initiated Command Sequences .....	75
4.8.1	Client Session Set-Up Command Sequence .....	76
4.8.1.1	Client Initiales Session Set-Up Request .....	76
4.8.1.2	Network Rejects Client Session Request .....	78
4.8.1.3	Server Rejects Server Session Indication .....	78
4.8.1.4	Client Has Final UserDataQ .....	79
4.8.1.5	Client Initiates Early Release .....	79
4.8.1.6	Server Does not respond to serverSessionSetUpIndication .....	80
4.8.1.7	Network Rejects Server's Resource AllocationStep 7 (Network): .....	80
4.8.1.8	Client Unable to Use Resources .....	80
4.8.2	Client Session Release Command Sequence .....	81
4.8.2.1	Client Initiates Release Request .....	81
4.8.2.2	Network Rejects Client Release Request .....	82
4.8.2.3	Server Rejects Server Release Indication .....	82
4.8.3	Client Initiated Status Command Sequence .....	82
4.9	Server Initiated Command Sequences .....	83
4.9.1	Server Continuous Feed Session Set-Up Command Sequence .....	83
4.9.1.1	Server Initiates Continuous Feed Session Set-Up .....	84

4.9.2	Server Add Resource Command Sequence .....	84
4.9.2.1	Server Initiates Add Resource Request .....	85
4.9.3	Server Session Delete Resource Command Sequence.....	86
4.9.4	Server Session Release Command Sequence .....	87
4.9.4.1	Server Initiates Release Request .....	87
4.9.4.2	Network Rejects Server Release Request.....	88
4.9.4.3	Client Rejects Client Release Indication .....	88
4.9.5	Server Continuous Feed Session Release Command Sequence.....	88
4.9.5.1	Server Initiates Continuous Feed Session Release Request.....	89
4.9.5.2	Network Rejects Server Release Request.....	90
4.9.5.3	Client Rejects Client Release Indication .....	90
4.9.6	Server Status Command Sequence .....	90
4.9.7	Server Session Forward Command Sequence.....	91
4.9.7.1	Client Initiates Session Set-Up.....	92
4.9.7.2	Network Rejects Forward.....	93
4.9.8	Server Session Transfer Command Sequence.....	93
4.9.8.1	Server A Initiates Session Transfer .....	94
4.9.8.2	Network Rejects Transfer Request .....	95
4.9.8.3	Server B Rejects the Transfer Request .....	95
4.9.8.4	Server B Unable to Allocate Resources for Transfer.....	96
4.9.8.5	Client Rejects Transfer.....	96
4.9.9	Transferred Session Release .....	96
4.9.9.1	SRM is Selecting sessionids .....	96
4.9.9.2	Server is Selecting sessionid .....	96
4.10	Network Initiated Command Sequences .....	97
4.10.1	Network Initiated Session Release Conunand Sequence .....	98
4.10.1.1	Network Initiates Session Release .....	98
4.10.2	Network Initiated Continuous Feed Session Release Command Sequence.....	98
4.10.2.1	Network Initiates Continuous Feed Session Release.....	99
4.10.3	Network Initiated Client Status Command Sequence .....	100
4.10.3.1	Network Initiates Client Status command sequence .....	100
4.10.4	Network Initiated Server Status Command Sequence.....	101
4.10.4.1	Network Initiates Server Status command sequence.....	101
4.11	Reset Procedures .....	101
4.11.1	Client Initiated Reset Command Sequence 1 .....	02
4.11.1.1	Client Initiates Reset command sequence.....	102
4.11.2	Server Initiated Reset Command Sequence .....	102
4.11.2.1	Server Initiates Reset command sequence .....	103
4.11.3	Network Initiated Reset Command Sequence .....	103
4.11.3.1	Network Initiates Reset command sequence .....	103
5.	USER-TO-USER INTERFACES .....	105
5.1	Introduction .....	105
5.1.1	Contents .....	105
5.1.2	Intended Usage .....	105
5.2	The User-to-User System Environment.....	107
5.2.1	U-U System Hardware User Entities .....	107
5.2.2	U-U System Logical Entities .....	107
5.2.3	Application and Service Interfaces .....	109
5.2.4	Categorization of Client Library Interface Sets 1 .....	10
5.2.4.1	Consumer Client 1 .....	10
5.2.4.2	Producer Client III .....	
5.2.4.3	Client Library Profiles 1 1 .....	1
5.2.5	Core Interfaces.....	112
5.2.5.1	Core Client Application Portability Library .....	113
5.2.5.2	Core Client Service Inter-operability Library .....	115
5.2.6	Extended Interfaces.....	116
5.2.6.1	Extended Client Application Portability Library .....	117
5.2.6.2	Extended Client Service-interoperability Library 1 1 .....	8
5.3	Overview of the Interface Definition Language(IDL) .....	118
5.3.1	Operations .....	120
5.3.2	Attributes .....	121

5.3.3	Language Mapping.....	121
5.3.4	Encoding .....	121
5.3.5	Typographical Conventions .....	122
5.3.6	Syntactical Conventions.....	122
5.4	Common Definitions .....	122
5.4.1	Basic Types.....	122
5.4.2	Entity Identification .....	123
5.4.3	Interface Identification .....	124
5.4.4	Access Roles for Operations .....	126
5.4.4.1	Syntax for Access Control 1 .....	26
5.4.5	Exceptions .....	127
5.4.6	Stream and Event Synchronization 1 .....	30
5.5	Application Portability Interfaces(API).....	131
5.5.1	Core Interfaces .....	131
5.5.1.1	Base .....	132
5.5.1.1.1	Summary of Base Primitives 1.....	32
5.5.1.1.2	DSM Base dose.....	133
5.5.1.1.3	DSM Base destroy .....	133
5.5.1.2	Access .....	133
5.5.1.2.1	Setting Permissions.....	134
5.5.1.2.2	Access Definitions .....	135
5.5.1.3	Stream .....	136
5.5.1.3.1	Stream Definitions, Exceptions .....	137
5.5.1.3.2	Normal Play Time Temporal Positioning .....	137
5.5.1.3.2.1	Application NPT Values .....	138
5.5.1.3.3	Summary of Stream Primitives .....	138
5.5.1.3.4	Stream State Machine .....	139
5.5.1.3.4.1	State Machine .....	139
5.5.1.3.4.2	Basic State Machine.....	141
5.5.1.3.4.3	Complete State machine.....	142
5.5.1.3.5	DSM Stream pause .....	143
5.5.1.3.6	DSM Stream resume .....	144
5.5.1.3.7	DSM Stream status.....	145
5.5.1.3.8	DSM Stream reset.....	146
5.5.1.3.9	DSM Stream jump.....	146
5.5.1.3.10	DSM Stream play .....	147
5.5.1.4	File .....	148
5.5.1.4.1	File Definitions, Exceptions .....	148
5.5.1.4.2	Summary of File Primitives .....	149
5.5.1.4.3	DSM File read.....	149
5.5.1.4.4	DSM File write .....	150
5.5.1.5	Directory .....	151
5.5.1.5.1	Directory Definitions, Exceptions.....	152
5.5.1.5.2	Summary of Directory Primitives .....	154
5.5.1.5.3	DSM Directory list.....	155
5.5.1.5.4	DSM Directory resolve .....	156
5.5.1.5.5	DSM Directory bind .....	156
5.5.1.5.6	DSM Directory bind_context .....	157
5.5.1.5.7	rebind.....	158
5.5.1.5.8	DSM Directory rebind_context.....	158
5.5.1.5.9	DSM Directory unbind.....	159
5.5.1.5.10	DSM Directory new_context.....	160
5.5.1.5.11	DSM Directory bind_new_context .....	160
5.5.1.5.12	DSM Directory destroy.....	161
5.5.1.5.13	DSM Directory open .....	161
5.5.1.5.14	DSM Directory dose .....	162
5.5.1.5.15	DSM Directory get .....	163
5.5.1.5.16	DSM Directory put .....	164
5.5.1.6	Session.....	165
5.5.1.6.1	Service Transfer .....	165
5.5.1.6.2	Sununary of Session Primitives .....	166
5.5.1.6.3	DSM Session attach .....	166

5.5.1.6.4	DSM Session detach .....	167
5.5.1.7	ServiceGateway .....	168
5.5.1.7.1	Summary of ServiceGateway Primitives .....	168
5.5.1.8	First .....	168
5.5.1.8.1	Summary of First Primitives .....	168
5.5.1.8.2	DSM First root .....	169
5.5.1.8.3	DSM First Service .....	169
5.5.2	Extended Interfaces .....	169
5.5.2.1	Download .....	171
5.5.2.1.1	Download Definitions, Exceptions .....	171
5.5.2.1.2	Summary of Download Primitives .....	171
5.5.2.1.3	DSM Download info .....	171
5.5.2.1.4	DSM Download alloc .....	172
5.5.2.1.5	DSM Download Start .....	172
5.5.2.1.6	DSM Download cancel .....	173
5.5.2.2	Event .....	173
5.5.2.2.1	Event Definitions, Exceptions .....	174
5.5.2.2.2	Summary of Event Primitives .....	174
5.5.2.2.3	DSM Event subscribe .....	174
5.5.2.2.4	DSM Event unsubscribe .....	175
5.5.2.2.5	DSM Event notify .....	176
5.5.2.3	Composite .....	177
5.5.2.3.1	Summary of Composite Primitives .....	177
5.5.2.3.2	DSM Composite list_subs .....	177
5.5.2.3.3	DSM Composite bind_subs .....	178
5.5.2.3.4	DSM Composite unbind_subs .....	179
5.5.2.4	View .....	179
5.5.2.4.1	Non-Database View .....	180
5.5.2.4.2	DatabaseView .....	180
5.5.2.4.3	View Procedures .....	180
5.5.2.4.4	Definition: View Style Attribute .....	181
5.5.2.4.5	View Definitions: Statement, Result .....	182
5.5.2.4.6	Summary of View Primitives .....	182
5.5.2.4.7	DSM View query .....	183
5.5.2.4.8	DSM View read .....	184
5.5.2.4.9	DSM View execute .....	185
5.5.2.5	State .....	185
5.5.2.5.1	Summary of State Primitives 1 .....	85
5.5.2.5.2	DSM State suspend .....	186
5.5.2.5.3	DSM State resume .....	187
5.5.2.6	Interfaces .....	187
5.5.2.6.1	TCKind Constants .....	188
5.5.2.6.2	Exception TCKind Constants .....	189
5.5.2.6.3	Interfaces Definitions .....	190
5.5.2.6.4	Summary of Interfaces Primitives .....	190
5.5.2.6.5	DSM Interfaces show .....	190
5.5.2.6.6	DSM Interfaces define .....	192
5.5.2.6.7	DSM Interfaces check .....	193
5.5.2.6.8	DSM Interfaces undefine .....	194
5.5.2.7	Security .....	194
5.5.2.7.1	DSM Security authenticate .....	194
5.5.2.8	Config .....	195
5.5.2.8.1	Config Definitions .....	197
5.5.2.8.2	Summary of Config Primitives .....	197
5.5.2.8.3	DSM Config inquire .....	197
5.5.2.8.4	DSM Config wait .....	197
5.5.2.9	LifeCycle .....	198
5.5.2.9.1	DSM LifeCycle create .....	198
5.5.2.10	Kind .....	199
5.5.2.10.1	Summary of Kind Primitives 1 .....	99
5.5.2.10.2	DSM_Kind_has_a .....	199
5.5.2.10.3	DSM_Kind_is_a .....	200

5.5.3	C Language Mappings .....	201
5.5.3.1	Scoped Identifiers .....	201
5.5.3.2	C Mapping for Operations .....	201
5.5.3.2.1	C Mapping for Basic Data Types .....	202
5.5.3.2.2	Constants .....	202
5.5.3.2.3	Struct Types .....	202
5.5.3.2.4	Sequence Types .....	202
5.5.3.2.5	Strings .....	203
5.5.3.2.6	Any .....	203
5.5.3.2.7	ev .....	203
5.5.3.2.8	Object .....	203
5.5.3.3	API Definitions .....	204
5.5.3.3.1	C Mapping for the Synchronous Interface .....	204
5.5.3.3.1.1	Base .....	204
5.5.3.3.1.2	Access .....	204
5.5.3.3.1.3	Stream .....	205
5.5.3.3.1.4	File .....	206
5.5.3.3.1.5	Directory .....	206
5.5.3.3.1.6	Session .....	207
5.5.3.3.1.7	First .....	207
5.5.3.3.1.8	Event .....	208
5.5.3.3.1.9	Download .....	208
5.5.3.3.1.10	Composite .....	208
5.5.3.3.1.11	View .....	209
5.5.3.3.1.12	State .....	209
5.5.3.3.1.13	Interfaces .....	210
5.5.3.3.1.14	Security .....	210
5.5.3.3.1.15	LifeCycle .....	210
5.5.3.3.1.16	Kind .....	210
5.5.3.3.2	C Mapping for the Synchronous Deferred Interface .....	211
5.5.3.3.2.1	Config .....	211
5.5.3.3.2.2	How to Convert Synchronous to Synchronous Deferred .....	211
5.6	Service Interoperability Interfaces(SII) .....	211
5.6.1	ConnBinder and Resource to Connection Association .....	212
5.6.1.1	Selector .....	214
5.6.2	Remote Procedure Call .....	214
5.6.3	The Object Reference .....	214
5.6.3.1	Min Protocol Profile .....	215
5.6.3.2	Child Protocol Profile .....	216
5.6.3.3	Options Protocol Profile .....	216
5.6.3.4	Lite Protocol Profiles .....	217
5.6.3.5	BIOP Protocol Profile .....	217
5.6.3.6	ONC Protocol Profile .....	218
5.6.4	ServiceContextList .....	218
5.6.4.1	ServiceContext .....	219
5.6.5	Core Interfaces .....	220
5.6.5.1	Base .....	220
5.6.5.2	Access .....	220
5.6.5.3	Stream .....	222
5.6.5.3.1	Transport and Application Level NPT .....	224
5.6.5.3.2	Consistent Quantization Rules .....	224
5.6.5.4	File .....	224
5.6.5.5	BindingIterator .....	225
5.6.5.6	NamingContext .....	226
5.6.5.7	Directory .....	227
5.6.6	Extended Interfaces .....	229
5.6.6.1	SessionUU .....	229
5.6.6.1.1	PartialPath .....	230
5.6.6.2	ServiceGatewayUU .....	230
5.6.6.2.1	Summary of ServiceGatewayUU Primitives .....	230
5.6.6.3	SessionSI .....	231
5.6.6.4	ServiceGatewaySI .....	231

5.6.6.4.1	Summary of ServiceGatewaySI Primitives.....	232
5.6.6.5	DownloadSI .....	232
5.6.6.6	Event .....	235
5.6.6.7	Composite .....	236
5.6.6.8	View .....	238
5.6.6.9	State .....	240
5.6.6.10	Interfaces .....	241
5.7	Application Boot Process .....	241
5.7.1	Session attach() Pre-conditions .....	242
5.7.2	Session attach() Procedure .....	243
5.7.2.1	Resolving Path-specific Parameters .....	243
5.7.2.1.1	Post-condition.....	244
5.7.2.2	Establishing the U-N Session.....	244
5.7.2.2.1	ClientSessionSetupRequest.....	244
5.7.2.2.2	ClientSessionSetupConfirm .....	245
5.7.2.2.3	Session Establishment Post-conditions .....	246
5.7.2.3	Download.....	246
5.7.3	Session Tear-down.....	248
5.7.4	Session Transfer Implications.....	248
6.	USER COMPATIBILITY .....	249
6.1	Compatibility Descriptors .....	249
6.1.1	IEEE OUI Specifier 25 .....	1
7.	USER-TO-NETWORK DOWNLOAD .....	252
7.1	Overview .....	252
7.1.1	Download Network Models .....	253
7.1.2	Preconditions and Assumptions .....	254
7.2	Download Message Set.....	255
7.2.1	Download Control Message Format .....	255
7.2.2	Download Data Message Format .....	255
7.2.2.1	DSM-CC Download Data Header .....	255
7.3	Message Descriptions .....	256
7.3.1	DownloadInfoRequest.....	257
7.3.2	DownloadInfoResponse and DownloadInfoIndication .....	257
7.3.3	DownloadDataBlock.....	259
7.3.4	DownloadDataRequest.....	259
7.3.5	DownloadCancel.....	260
7.3.6	DownloadServerInitiate.....	263
7.4	Message Sequence for Flow-Controlled Download Scenario.....	263
7.4.1	Getting Download Protocol Parameters.....	264
7.4.2	Starting Download .....	265
7.4.3	Acknowledgments .....	265
7.4.4	Timers and Re-transmission .....	266
7.4.5	Abort .....	267
7.4.6	Flow-Controlled Scenario over Reliable Transport.....	267
7.5	Message Sequence for Data Carousel Scenario .....	267
7.5.1	Getting Data Carousel Parameters .....	267
7.5.2	Starting Acquisition and Module Re-Assembly.....	268
7.5.2.1	Pseudo-Code Example of Module Re-assembly .....	268
7.5.3	Timers .....	269
7.5.4	Module Coherency.....	270
7.5.5	Data Delivery Rate .....	270
7.6	Message Sequence for Non-Flow-Controlled Download Scenario .....	270
7.6.1	Getting Download Protocol Parameters 27 .....	1
7.6.2	Image Assembly and Coherency 27 .....	1
7.6.3	Timers .....	271
7.7	Protocol State Machines for flow-controlled download scenario 27 .....	1
7.7.1	State Variables common to Client and Download Server .....	272
7.7.1.1	Service Type: reliableService, unreliableService .....	272
7.7.1.2	Download configured bufferSize: bufferSize.....	272
7.7.1.3	Download configured maximumBlockSize: blockSize .....	272

7.7.1.4	Download Identifier: Did .....	272
7.7.1.5	Download negotiated blockSize; Did.blockSize.....	272
7.7.1.6	Download negotiated windowSize: Did. windowSize .....	272
7.7.1.7	Download negotiated Acknowledgment Period: Did.ackPeriod .....	272
7.7.1.8	Download negotiated Window Timer; Did.tWindow .....	272
7.7.1.9	Download negotiated Scenario Timer; Did.tScenario .....	272
7.7.1.10	Download negotiated compatibilities; Did.compatibilities .....	272
7.7.1.11	Download Number of Modules: Did.numModules .....	272
7.7.1.12	Download Module Identifier: Did.moduleId .....	272
7.7.1.13	Download Module Version; Did.moduleId.version .....	273
7.7.1.14	Download Module Size; Did.moduleId.moduleSize .....	273
7.7.1.15	Download Expired downloadid Holding timer; Did.tHold .....	273
7.7.2	Client-only State Variables .....	273
7.7.2.1	Download Lower Receive Window Edge; Did.NmoduleId, Did.NblockNum.....	273
7.7.2.2	Number received blocks; Did.Nblock.....	273
7.7.2.3	Acknowledgment threshold: Did.AckThreshold .....	273
7.7.3	Server-only State Variables .....	273
7.7.3.1	Lower Transmit Window Edge: Did.LmoduleId, Did.LblockNum .....	273
7.7.3.2	Upper Transmit Window Edge: Did.UmoduleId, Did.UblockNum .....	273
7.7.3.3	Data Sending Rate Timer: Did.tSend.....	273
7.7.4	Client Conditions .....	273
7.7.4.1	Invalid ServerId.....	273
7.7.4.2	Number of re-transmission exceeded .....	274
7.7.4.3	Unacceptable blockSize .....	274
7.7.4.4	Unacceptable WindowSize .....	274
7.7.4.5	Unacceptable Acknowledgment Period .....	274
7.7.4.6	Unacceptable Window Timer .....	274
7.7.4.7	Unacceptable Scenario Timer .....	274
7.7.4.8	Unacceptable Compatibilities .....	274
7.7.4.9	Unacceptable Module Table .....	274
7.7.4.10	Acknowledgment period full .....	274
7.7.4.11	Download complete .....	274
7.7.5	Download Server Conditions .....	274
7.7.5.1	Unacceptable maximumBlockSize .....	274
7.7.5.2	Unacceptable bufferSize.....	275
7.7.5.3	Unacceptable Compatibilities .....	275
7.7.6	Client Procedures.....	275
7.7.6.1	Initial Setup of State Variables.....	275
7.7.6.2	Sending DownloadDataRequest Messages.....	275
7.7.6.3	Sending DownloadCancel Messages .....	275
7.7.6.4	Increment Lower Receive Window Edge .....	275
7.7.6.5	Increment block counter.....	276
7.7.6.6	Transition to DCExpire State.....	276
7.7.7	Download Server Procedures .....	276
7.7.7.1	Initial Setup of State Variables.....	276
7.7.7.2	Increment Lower Transmit Window Edge.....	277
7.7.7.3	Set Upper Transmit Window Edge.....	277
7.7.7.4	Sending DownloadDataBlock Messages .....	277
7.7.7.5	Sending DownloadCancel Messages .....	277
7.7.7.6	Transition to DSExpire State.....	277
7.7.8	State Machine SDL .....	277
7.8	Partial Protocol State Machines for non-flow-controlled download scenario .....	277
8.	STREAM DESCRIPTORS .....	279
8.1	Normal Play Time .....	279
8.1.1	NPT Reference Descriptor .....	279
8.1.2	Reconstruction of NPT .....	280
8.1.3	NPT Conversion to Seconds and Microseconds .....	281
8.1.4	NPT Uncertainty.....	281
8.1.4.1	Frequency of NPT Reference Descriptor 28 .....	1
8.1.5	NPT Endpoint Descriptor.....	282
8.2	Stream Mode Descriptor .....	282

8.3	Stream Event Descriptor .....	283
9.	TRANSPORT.....	284
9.1	DSM-CC Requirements on Lower-Level Network Transport Protocol .....	284
9.1.1	U-N Message Categories.....	284
9.1.2	U-U Interface Categories.....	284
9.2	Encapsulation within MPEG-2 Transport Streams.....	285
9.2.1	Role of MPEG-2 Transport Stream in the Protocol Stack.....	285
9.2.2	DSM-CC Sections .....	285
9.2.2.1	Semantic definition of fields in DSMCC_section.....	286
9.2.3	DSM-CC Stream Types.....	288
9.2.4	DSM-CC Multi-protocol Encapsulation.....	288
9.2.5	U-N Message Categories.....	289
9.2.6	U-U Service Inter-operability Interface using Remote Procedure Call.....	289
9.2.7	DSM-CC Stream Descriptors .....	289
9.2.7.1	Semantic definition of fields in DSM-CC Descriptor List .....	289
9.3	Encapsulation within MPEG-2 Program Streams.....	289
9.3.1	DSM-CC Stream Descriptors .....	289
9.3.1.1	Semantic definition of fields in DSM-CC_program_stream_Descriptor List.....	290
9.3.2	U-N Messages and U-U SSI.....	290
10.	U-N SWITCHED DIGITAL BROADCAST - CHANNEL CHANGE PROTOCOL .....	291
10.1	Overview.....	291
10.1.1	Preconditions and Assumptions .....	291
10.1.2	General Message Format 29.....	1
10.2	Switched Digital Broadcast Channel Change Protocol Messages 29.....	1
10.2.1	Use of Private Data in SDB CCP messages .....	292
10.2.2	Use of BroadcastProgramId in SDB CCP messages .....	292
10.2.3	SDB CCP message definitions .....	292
10.2.3.1	SDBProgramSelectRequest message definition.....	293
10.2.3.2	SDBProgramSelectConfirm message definition .....	293
10.2.3.3	SDBProgramSelectIndication message definition .....	294
10.2.3.4	SDBProgramSelectResponse message definition.....	294
10.3	SDB Channel Change Protocol Command Scenarios .....	294
10.3.1	Client Initiated Program Select Command Sequence.....	294
10.3.2	SDB Server Initiated Program Select Command Sequence.....	296
10.4	SDB Reason and Response Codes .....	297
10.4.1	SDB Reason Codes .....	297
10.4.2	SDB Response Codes .....	298
10.5	SDB State Machine .....	298
10.5.1	SDB State Machine for the Client Side .....	298
10.5.2	State machine for the SDB Server Side.....	300
11.	U-U OBJECT CAROUSEL.....	303
11.1	Introduction.....	303
11.2	Concepts.....	304
11.2.1	Supported U-U Objects and Interfaces.....	304
11.2.2	Service Domain and Service Gateway.....	304
11.2.3	Object References .....	305
11.2.4	Transport of BIOP Messages.....	305
11.2.5	Module Delivery Parameters .....	306
11.2.6	Taps.....	306
11.3	Broadcast Inter ORB Protocol.....	307
11.3.1	Inter-operable Object Reference (IOR) .....	307
11.3.1.1	Profile Body Definition .....	307
11.3.1.1.1	Object Location Component.....	307
11.3.1.1.2	ConnBinder Component .....	307
11.3.2	Message Set Definition .....	308
11.3.2.1	Generic Object Message Format.....	308
11.3.2.2	Directory Message Format.....	310
11.3.2.3	File Message Format .....	311
11.3.2.4	Stream Message Format .....	311

11.3.2.5	Service Gateway Message Format .....	313
11.3.3	Transport Definitions .....	313
11.3.3.1	BIOP Messages.....	313
11.3.3.2	Module Delivery Parameters .....	313
11.3.3.3	IOR of Service Gateway .....	314
11.4	MPEG-2 Descriptors.....	315
11.4.1	Carousel identifier descriptor .....	316
11.4.2	Association tag descriptor .....	316
11.4.3	Deferred association tags descriptor.....	318
12.	USER-TO-NETWORK PASS-THRU MESSAGES.....	319
12.1	Overview and the General Message Format.....	319
12.2	Pass-Thru Messages.....	319
12.2.1	Use of PassThruData() structure in Pass-Thru messages.....	320
12.2.2	Pass-Thru message definitions .....	321
12.2.2.1	PassThruRequest .....	321
12.2.2.2	PassThruIndication .....	321
12.2.2.3	PassThruReceiptRequest.....	321
12.2.2.4	PassThruReceiptConfirm .....	322
12.2.2.5	PassThruReceiptIndication .....	322
12.2.2.6	PassThruReceiptResponse.....	323
12.3	User-to-Network Pass-Thru Message Field Data Types.....	323
12.4	Pass-Thru Message Scenario .....	324
12.4.1	Pass-Thru Message scenario.....	324
12.4.1.1	The Sending User sends a PassThruRequest.....	324
12.5	Pass-Thru Receipt Message Scenario .....	324
12.5.1	Pass-Thru Receipt Message scenario.....	325
12.5.1.1	The Sending User sends a PassThruReceiptRequest.....	325
12.6	Pass-Thru Response Codes.....	326
12.7	Pass-Thru Type Codes .....	326
12.8	State Machine .....	326
<b>ANNEX A (NORMATIVE) USER-NETWORK PROTOCOL STATE MACHINES.....</b>		<b>327</b>
A.1	Introduction .....	327
A.2	U-N Session.....	327
A.3	U-N Download Flow Controlled Scenario.....	364
A.4	U-N Switched Digital Broadcast Channel Change Protocol.....	377
A.5	U-N Pass-Thru .....	390
<b>ANNEX B (INFORMATIVE) APPLICATION EXAMPLES.....</b>		<b>399</b>
B.1	Introduction .....	399
B.2	Video Stream Play.....	399
B.3	Building a Directory Hierarchy 40 .....	1
B.4	Movie Information Database .....	402
B.5	View as a Personalized Directory.....	408
<b>ANNEX C (INFORMATIVE) ONC RPC XDR MAPPINGS .....</b>		<b>410</b>
C.1	Overview .....	410
C.2	General RPC Message Formats .....	410
C.3	CORBA IDL C to XDR Mapping .....	412
C.3.1	Mapping for Integer Data Types .....	412
C.3.2	Mapping for void.....	412
C.3.3	Mapping for Constants.....	413
C.3.4	Mapping for octet.....	413
C.3.5	Mapping for Fixed-length Constructed Types .....	413
C.3.5.1	Mapping for struct .....	413
C.3.6	Mapping for sequences.....	413
C.3.6.1	Example; Mapping for opaque .....	413
C.3.6.2	Example: Mapping for PathSpec.....	414
C.3.7	Mapping for string .....	415
C.4	DSM-CC ONC Protocol Profile for the Interoperable Object Reference.....	415
C.5	Exceptions C.6 Request and Reply Header Structures .....	417

C.7 DSM-CC RPC Program Numbers .....	418
C.7.1 RPC Program Dispatch Tables Mapping .....	418
<b>ANNEX D (INFORMATIVE) USING DSM-CC U-N SESSION MESSAGES WITH ATM .....</b>	<b>421</b>
D. 1 Methods of using DSM-CC over ATM 42 .....	1
D.1.1 SessionMethod.....	421
D. 1.2 Network Method with AddResource messages between the Server and the SRM 42.....	1
D. 1.3 Network Method with NO AddResource messages between the Server and the SRM 42 .....	1
D. 1.4 Integrated Method .....	422
D.2 Association of DSM-CC connection resources to ATM SVCs.....	423
D.2.1 DSM-CC resourceId Mapping into Q.293 1 .....	423
D.3 Session Method Command Sequences .....	424
D.3.1 Session Set-Up .....	424
D.3.1.1 Client Session Set-Up.....	425
D.3.2 Add Resource Request.....	428
D.3.2.1 Add Resource Request by the Server.....	429
D.3.3 Resource Deletion.....	430
D.3.3.1 Resource Deletion by the Server 43.....	1
D.3.4 Session Tear-Down .....	433
D.3.4.1 Session Tear-Down by Server .....	434
D.3.4.2 Session Tear-Down by Client.....	436
D.4 Network Method with DSM-CC AddResource messages between the Server and SRM.....	437
D.4.1 Session Set-Up .....	437
D.4. 1 1 Client Session Set-Up, Server ATM Connection Set-Up .....	437
D.4.2 Add Resource Request.....	440
D.4.2.1 Add Resource Request by Server and ATM SVC Connection Set-Up by Server .....	440
D.4.3 Resource Deletion.....	442
D.4.3.1 Resource Deletion Request by Server and ATM SVC Connection Release by Server .....	442
D.4.4 Session Tear-Down .....	443
D.4.4.1 Session Tear-Down Request by Server and ATM SVC Connection Release by Client .....	443
D.4.4.2 Session Tear-Down Request by Client and ATM SVC Connection Release by Server .....	444
D.4.4.3 Session Tear-Down Request by Server and ATM SVC Connection Release by Server .....	445
D.5 Network Method with NO DSM-CC AddResource messages between the Server and SRM .....	446
D.5 1 Session Set-Up.....	446
D.5. 1 1 Client Session Set-Up.....	447
D.5.2 Add Resource Request.....	447
D.5.2.1 Add Resource Request by the Server.....	447
D.5.3 Connection Clearing .....	449
D.5.3.1 Connection Clearing by the Server .....	449
D.5.3.2 Connection Clearing by the Client .....	451
D.5.4 Session Tear-Down 45.....	1
D.5.4.1 Session Tear-Down by Server .....	451
D.5.4.2 Session Tear-Down by Client.....	452
D.6 Integrated Method Command Sequences .....	453
D.6.1 Session Set-Up.....	454
D.6. 1 1 Client Session Set-Up.....	454
D.6. 1.2 Server Session Set-Up.....	455
D.6.2 Integrated Method for Adding Resources .....	455
D.6.3 Connection Clearing 45.....	6
D.6.4 Session Tear-Down.....	456
D.6.4.1 Server Session Tear-Down.....	457
D.6.4.2 Client Session Tear Down .....	457
D.7 References .....	457
<b>ANNEXE (INFORMATIVE) UNO INTER-OPERABLE RPC PROTOCOL STACK.....</b>	<b>459</b>
E.1 Abstract .....	459
E.2 Motivation.....	459
E.3 Solution Space.....	459
E.4 Inter-operation Framework.....	460
E.5 Protocol Selection .....	461
E.6 Common Data Representation 46.....	1
E.6.1 Encapsulation .....	462

E.6.2 Alignment.....	462
E.6.3 Primitive Data Types.....	462
E.6.4 Compound Types.....	463
E.6.5 TypeCode.....	463
E.7 UNO Session Protocol.....	464
E.7.1 Message Set.....	464
E.7.1.1 Request Message.....	464
E.7.1.2 Reply.....	465
E.7.1.3 CancelRequest.....	466
E.7.1.4 LocateRequest.....	466
E.7.1.5 LocateReply.....	466
E.7.1.6 CloseConnection.....	466
E.7.1.7 MessageError.....	466
E.7.2 Session Semantics.....	466
E.8 Transport and Network Semantics.....	467
<b>ANNEXE (INFORMATIVE) USE OF U-U OBJECT CAROUSEL.....</b>	<b>468</b>
F.1 Introduction.....	468
F.2 Purpose of U-U Object Carousels.....	468
F.3 IDL structures.....	468
F.3.1 Inter-operable object Reference.....	468
F.3.2 Generic object Message.....	470
F.3.3 Directory Message.....	470
F.4 Support for New Object Representations 47.....	1
F.5 How to resolve an object from its IOR.....	472
F.6 Service Gateway and Download Support.....	474
F.7 U-U Object Carousels on top of MPEG-2 TS Broadcast Networks.....	475
<b>ANNEX G (INFORMATIVE) SHARED RESOURCES AND THE ASSOCIATION TAG.....</b>	<b>477</b>
G.1 Introduction.....	477
G.2 Use of the Association Tag.....	477
G.3 Use of the SharedResource Descriptor.....	478
G.4 Use of the SharedRequestId Descriptor.....	478
G.5 Common Examples of Use -479.....	
G.5.1 Download Phase, Multiple ATM SVCs.....	479
G.5.1.1 End-to-End ATM.....	479
G.5.1.2 Non-ATM HFC Client View.....	480
G.5.2 Video Play Phase, Multiple ATM SVCs.....	481
G.5.2.1 End-to-End ATM.....	481
G.5.2.2 Non-ATM HFC Client View.....	482
G.5.3 Single Asymmetrie ATM SVC.....	483
G.5.3.1 End-to-End ATM.....	483
G.5.3.2 Non-ATM HFC Client View.....	484
G.5.4 Single Asymmetrie ATM PVC.....	486
G.5.5 Download Phase, Multiple ATM PVCs.....	486
G.5.6 Video Play Phase, Multiple ATM PVCs.....	486
G.5.7 Use of sharedResourceRequest Descriptors.....	486
<b>ANNEX H (INFORMATIVE) SWITCHED DIGITAL BROADCAST SERVICE.....</b>	<b>487</b>
H.1 Introduction.....	487
H.2 Switched Digital Broadcast Service.....	487
H.3 Functional Flows.....	488
H.3.1 Broadcast Program Configuration.....	488
H.3.2 Client Service Profile Transfer to the SDB Server.....	489
H.3.3 Broadcast Program Guide Transfer to Client.....	490
H.3.4 Switched Digital Broadcast Service Session Establishment.....	490
H.3.5 Client Initiated Channel Changes.....	492
H.3.6 Network Initiated Channel Changes.....	493
H.3.7 Digital Broadcast Session Release.....	495
<b>ANNEX I (INFORMATIVE) EXAMPLE U-N LIFE CYCLE WALK THROUGH.....</b>	<b>497</b>
I.1 Introduction.....	497

I.2 General Flow .....	497
I.3 U-N-Configuration .....	498
I.3.1 Pre Conditions .....	498
I.3.2 Procedure .....	498
I.3.3 Post Conditions 49 .....	8
I.4 U-N Session Setup.....	499
I.4.1 Pre Conditions .....	499
I.4.2 Procedure .....	499
I.4.3 Post Conditions .....	502
I.5 U-N Download .....	503
I.5.1 Pre Conditions .....	503
I.5.2 Procedure .....	504
I.5.3 Post Conditions .....	504
<b>ANNEX J (INFORMATIVE) EXAMPLE OF AN OSI NSAP ADDRESS FORMAT .....</b>	<b>505</b>
J.1 Purpose.....	505
J.2 Introduction .....	505
J.3 E. 164 NSAP.....	505
<b>ANNEX K (INFORMATIVE) STREAM PLAYLIST.....</b>	<b>507</b>
K.1 Overview .....	507
K.2 DSM QStream next.....	509
<b>ANNEX L (INFORMATIVE) SERVICE TRANSFER MESSAGE FLOWS .....</b>	<b>510</b>
L.1 Introduction.....	510
L.1.1 Use of Service transfer in the normal course of Service.....	510
L.1.2 Use of Service Transfer in emergency cases .....	511
L.2 Basic application level Service Transfer.....	511
L.2.1 Service Transfer: sourceServer to destinationServer with sourceServer Session Release .....	511
L.2.2 Service Transfer: sourceServer to destinationServer, Service maintained on sourceServer 5 ..	12
L.3 Enhanced application level Service Transfer .....	513
L.3.1 Release the Session with the sourceServer .....	513
L.3.2 Maintain minimum resources with the sourceServer 5 .....	14
L.3.3 Maintain the Service with the sourceServer .....	515
L.3.4 Fall back to Server A after Session release with the sourceServer.....	515
L.3.5 Resumption of the full context on Server A after reduced Session.....	515
L.3.6 Emergency Service Transfer .....	516
<b>ANNEX M (INFORMATIVE) T.120 INTER-WORKING .....</b>	<b>519</b>
M.1 Introduction .....	519
M.2 Reference Model for side-by-side integrated DSM-CC/T. 120 5.....	19
M.3 Features, Functions and Services of the DSM-CC and the T.120 specifications.....	521
M.3.1 Features, Functions and Services of DSM-CC .....	521
M.3.2 Features, Functions and Services of T.120.....	521
M.3.3 Inter-working of DSM-CC and T. 120 Features, Functions and Services.....	521
M.4 DSM-CC and T. 120 Components Harmonized .....	522
M.5 Specifics for inter-operation between DSM-CC and T. 120 .....	523
M.5.1 Terminal 1 creates a conference .....	524
M.5.2 Terminal 2 queries a conference.....	524
M.5.3 Terminal 2 joins the conference.....	524
M.6 T. 120 Service within DSM-CC .....	536
M.6.1 An Example of Extending DSM-UU to provide custom interfaces .....	536
<b>ANNEX N (INFORMATIVE) THE RELATION OF DSM-CC TO MHEG-5 .....</b>	<b>539</b>
N.1 Overview .....	539
N.2 Name Space .....	539
N.2.1 MHEG Object References.....	540
N.2.2 Content References .....	540
N.3 Stream Events and Normal Play Time .....	540
N.4 Example of DSM-CC file structure for an application.....	541
N.5 Example of Mapping High-Level API Actions on DSM-CC U-U Primitives.....	542