

ISO/IEC 18092:2013-03 (E)

Information technology - Telecommunications and information exchange between systems - Near Field Communication - Interface and Protocol (NFCIP-1)

Contents		Page
Foreword		v
Introduction		vi
1	Scope	1
2	Conformance	1
3	Normative references	1
4	Terms and definitions	2
5	Conventions and notations	4
5.1	Representation of numbers	4
5.2	Names	4
6	Abbreviated terms	4
7	General	5
8	RF field	6
8.1	Values	6
8.2	Passive communication Mode	6
8.3	Active communication Mode	6
8.4	External RF field detection	6
9	RF Signal Interface	6
9.1	Bit duration	6
9.2	Active communication mode	7
9.2.1	Requirements for fc/128	7
9.2.2	Requirements for fc/64 and fc/32	7
9.3	Passive communication mode	8
9.3.1	Initiator to Target requirements for fc/128	8
9.3.2	Target to Initiator requirements for fc/128	9
9.3.3	Initiator to Target requirements for fc/64 and fc/32	9
9.3.4	Target to Initiator requirements for fc/64 and fc/32	9
10	General Protocol flow	10
11	Initialisation	10
11.1	RF Collision Avoidance	11
11.1.1	Initial RF Collision Avoidance	11
11.1.2	Response RF Collision Avoidance	12
11.2	Passive communication mode	13
11.2.1	Initialisation and Single Device Detection at fc/128	13
11.2.2	Initialisation and SDD at fc/64 and fc/32	13
11.3	Active communication mode	17
11.3.1	Initialisation at fc/128, fc/64, and fc/32	17
11.3.2	Active communication mode RF Collision Avoidance	17
12	Transport Protocol	18

12.1	Transport Data	18
12.2	Passive communication mode Activation flow	18
12.3	Active communication mode Activation flow	19
12.4	Commands	22
12.5	Activation of the protocol	22
12.5.1	Attribute Request and Response Commands	22
12.5.2	Wakeup Request and Response Commands	28
12.5.3	Parameter Selection Request and Response Commands	30
12.6	Data Exchange Protocol	33
12.6.1	Data Exchange Protocol Request and Response	33
12.6.2	Response timeout extension	37
12.6.3	Attention - Target present	37
12.6.4	Protocol operation	37
12.6.5	Multi Activation	37
12.6.6	More information (Chaining)	38
12.7	Deactivation of the protocol	38
12.7.1	Deselect Request and Response command	39
12.7.2	Release Request and Response commands	40
Annex A (normative) CRC calculation		42
A.1	CRC for Active and Passive communication mode at fc/128	42
A.2	Example of CRC calculation at fc/128	42
A.3	CRC for Active and Passive communication mode at fc/64 and fc/32	43
A.4	Example of CRC calculation at fc/64 and fc/32	43
Annex B (informative) SAK		44