

ISO/IEC 15961-4:2016-08 (E)

Information technology - Radio frequency identification (RFID) for item management: Data protocol - Part 4: Application interface commands for battery assist and sensor functionality

| Contents | | Page |
|--------------------|--|-------------|
| Foreword | | iv |
| Introduction | | v |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | Conformance | 2 |
| 4.1 | General | 2 |
| 4.2 | Conformance of the Sensor Processor | 2 |
| 4.3 | Application conformance | 2 |
| 5 | Logical interface model | 3 |
| 5.1 | General | 3 |
| 5.2 | Application commands | 3 |
| 5.3 | The sensor information model for full function sensors | 3 |
| 5.4 | The sensor information model for simple sensors | 4 |
| 6 | Simple sensor commands | 5 |
| 6.1 | Current air interface reference | 5 |
| 6.2 | Memory mapped simple sensors | 5 |
| 6.3 | Ported simple sensors | 6 |
| 6.3.1 | Write-Sample-And-Configuration-Record | 6 |
| 6.3.2 | Read-Simple-Sensor-Data-Block | 8 |
| 6.3.3 | Other simple sensor commands | 10 |
| 7 | Full function sensors | 10 |
| 7.1 | General | 10 |
| 7.2 | Write-Sample-And-Configuration | 11 |
| 7.2.1 | Write-Sample-And-Configuration command | 11 |
| 7.2.2 | Write-Sample-And-Configuration response | 14 |
| 7.3 | Read-Alarm-Status | 15 |
| 7.3.1 | Read-Alarm-Status command | 15 |
| 7.3.2 | Read-Alarm-Status response | 16 |
| 7.4 | Read-Event-Record-Segments | 17 |
| 7.4.1 | Read-Event-Record-Segments command | 17 |
| 7.4.2 | Read-Event-Record-Segments response | 19 |
| 7.5 | Other full function sensor commands | 24 |
| Bibliography | | 25 |