

# ISO 15872:2002-11 (E)

## Aerospace - UNJ threads - Gauging

---

| <b>Contents</b>   |  | <b>Page</b> |
|---|--|-------------|
| Foreword .....  |  | iv          |
| <b>1</b>  | <b>Scope .....</b>   | <b>1</b>    |
| <b>2</b>  | <b>Normative references .....</b>                                  | <b>1</b>    |
| <b>3</b>  | <b>Terms, definitions, symbols and abbreviated terms .....</b>     | <b>1</b>    |
| <b>3.1</b>  | <b>Terms and definitions .....</b>                                 | <b>1</b>    |
| <b>3.2</b>  | <b>Symbols and abbreviated terms .....</b>                         | <b>2</b>    |
| <b>4</b>  | <b>Types of gauges .....</b>                                       | <b>3</b>    |
| <b>4.1</b>  | <b>Gauges and setting plugs for external product threads .....</b> | <b>3</b>    |
| <b>4.2</b>  | <b>Gauges for internal product threads .....</b>                   | <b>3</b>    |
| <b>5</b>  | <b>Reference temperature .....</b>                                 | <b>4</b>    |
| <b>6</b>  | <b>Function, design and use of gauges .....</b>                    | <b>4</b>    |
| <b>6.1</b>  | <b>Gauges for external threads .....</b>                           | <b>4</b>    |
| <b>6.2</b>  | <b>Gauging for internal threads .....</b>                          | <b>5</b>    |
| <b>7</b>  | <b>Setting gauges for external threads .....</b>                   | <b>6</b>    |
| <b>8</b>  | <b>Gauging of threads .....</b>                                    | <b>6</b>    |
| <b>Annex A (normative) Prevalence of gauging by GO gauges .....</b> |  | <b>26</b>   |
| <b>Bibliography .....</b>   |  | <b>27</b>   |