

# DIN EN 14035-21:2006-01 (E)

## Fireworks - Part 21: Jumping ground spinners - Specification and test methods

---

### Contents

	Page
<b>Foreword .....</b>	<b>4</b>
<b>1 Scope .....</b>	<b>6</b>
<b>2 Normative references .....</b>	<b>7</b>
<b>3 Terms and definitions .....</b>	<b>7</b>
<b>4 Construction .....</b>	<b>7</b>
<b>4.1 Means of ignition .....</b>	<b>7</b>
<b>4.2 Attachment of initial fuse .....</b>	<b>7</b>
<b>4.3 Protection of initial fuse .....</b>	<b>7</b>
<b>4.3.1 General .....</b>	<b>7</b>
<b>4.3.2 Initial fuse protected by fuse cover .....</b>	<b>7</b>
<b>4.3.3 Initial fuse protected by primary pack or selection pack .....</b>	<b>7</b>
<b>4.3.4 Initial fuse designed to resist side ignition .....</b>	<b>8</b>
<b>4.4 Materials of firework case .....</b>	<b>8</b>
<b>4.5 Integrity .....</b>	<b>8</b>
<b>4.6 Net explosive content .....</b>	<b>8</b>
<b>4.7 Visibility of fuse .....</b>	<b>8</b>
<b>5 Performance .....</b>	<b>8</b>
<b>5.1 Initial fuse .....</b>	<b>8</b>
<b>5.2 Principal effects .....</b>	<b>8</b>
<b>5.3 Functioning .....</b>	<b>8</b>
<b>5.4 Explosions .....</b>	<b>9</b>
<b>5.5 Motion of the jumping ground spinner .....</b>	<b>9</b>
<b>5.6 Burning matter .....</b>	<b>9</b>
<b>5.7 Projected debris .....</b>	<b>9</b>
<b>6 Primary pack or selection pack .....</b>	<b>9</b>
<b>7 Minimum labelling requirements .....</b>	<b>9</b>
<b>7.1 General .....</b>	<b>9</b>
<b>7.2 Type name and category .....</b>	<b>10</b>
<b>7.3 Safety information .....</b>	<b>10</b>
<b>7.3.1 General .....</b>	<b>10</b>
<b>7.3.2 Jumping ground spinners .....</b>	<b>10</b>
<b>7.3.3 Identification of top side .....</b>	<b>10</b>
<b>7.4 Name, address and telephone number of manufacturer or distributor or importer .....</b>	<b>10</b>
<b>7.5 Reference to this document .....</b>	<b>11</b>
<b>7.6 Printing .....</b>	<b>11</b>
<b>7.6.1 Labelling .....</b>	<b>11</b>
<b>7.6.2 Type size .....</b>	<b>11</b>
<b>7.7 Marking of very small jumping ground spinners .....</b>	<b>11</b>
<b>7.7.1 Reduced size .....</b>	<b>11</b>
<b>7.7.2 Reduced information .....</b>	<b>11</b>
<b>7.8 Additional information on the primary pack (if applicable) .....</b>	<b>11</b>
<b>8 Test methods .....</b>	<b>11</b>
<b>8.1 Attachment of initial fuse (type test and batch test) .....</b>	<b>12</b>
<b>8.1.1 Apparatus .....</b>	<b>12</b>

<b>8.1.2</b>	<b>Procedure .....</b>	<b>12</b>
<b>8.2</b>	<b>Performance (type test and batch test) .....</b>	<b>12</b>
<b>8.2.1</b>	<b>Test environment .....</b>	<b>12</b>
<b>8.2.2</b>	<b>Apparatus .....</b>	<b>12</b>
<b>8.2.3</b>	<b>Procedure .....</b>	<b>12</b>
<b>8.3</b>	<b>Determination of net explosive content (type test) .....</b>	<b>13</b>
<b>8.3.1</b>	<b>Apparatus .....</b>	<b>13</b>
<b>8.3.2</b>	<b>Procedure .....</b>	<b>13</b>
<b>8.4</b>	<b>Side ignition of initial fuse (type test) .....</b>	<b>13</b>
<b>8.4.1</b>	<b>Material .....</b>	<b>13</b>
<b>8.4.2</b>	<b>Test area .....</b>	<b>13</b>
<b>8.4.3</b>	<b>Apparatus .....</b>	<b>13</b>
<b>8.4.4</b>	<b>Test specimen .....</b>	<b>13</b>
<b>8.4.5</b>	<b>Procedure .....</b>	<b>14</b>
<b>8.5</b>	<b>Labelling (type test and batch test) .....</b>	<b>15</b>
<b>Annex A (normative) Type testing .....</b>		<b>16</b>
<b>Annex B (normative) Batch testing .....</b>		<b>23</b>
<b>Annex C (normative) Method for determination of smouldering rate of cigarette .....</b>		<b>26</b>
<b>Annex D (informative) A-Deviations .....</b>		<b>27</b>