ISO 13297:2020 (E)

Small craft — Electrical systems — Alternating and direct current installations

Contents

Foreword

1 Scope

2 Normative references

3 Terms and definitions

4 General requirements, DC and AC systems

5 General requirements, DC systems

6 General requirements, AC systems

7 Marking, AC systems

8 Batteries, DC systems

9 Battery-disconnect switch, DC systems

10 Power source options, AC systems

11 Inverters and inverter/chargers, AC systems

12 Overcurrent protection, DC systems

13 Overcurrent protection, AC systems

13.1 General
13.2 Supply circuits
13.3 Branch circuits

14 Ground-fault protection/earth-leakage protection, AC systems

15 Panel boards (switchboards), DC and AC systems

16 Panel boards (switchboards), AC systems

17 Conductors, DC and AC systems

18 Conductors, DC systems

19 Conductors, AC systems

20 System wiring, DC and AC systems

21 System wiring, DC systems

22 Socket outlets, DC systems

23 Socket outlets, AC systems

24 Appliances and equipment, AC systems

25 Ignition protection, DC and AC systems

26 Owner’s manual

Annex A (normative) Conductor requirements

Annex B (normative) Instructions to be included with owner's manual

Annex C (informative) Recommended system tests

Annex D (informative) Typical AC system diagrams

Annex E (informative) Overcurrent protection location options

Page count: 34