

# ISO 21919-2:2021 (E)

## Physical device control — Interfaces for automated machine tending — Part 2: Safety and control interface

---

### Contents

	Foreword
	Introduction
1	Scope
2	Normative references
3	Terms and definitions
4	Description of the interfaces
4.1	General
4.2	Characteristics of the interface
4.2.1	General
4.2.2	Conformance class
4.2.2.1	General
4.2.2.2	Conformance class 1: Minimum set of signals
4.2.2.2.1	General
4.2.2.2.2	Simple unloading
4.2.2.2.3	Simple loading
4.2.2.2.4	Simple combined unloading and loading
4.2.2.3	Conformance class 2: Extended set of signals
4.2.2.3.1	General
4.2.2.3.2	Unloading with non-coherent transfer, with/without clamping function
4.2.2.3.3	Unloading with coherent transfer
4.2.2.3.4	Loading with non-coherent transfer, with/without clamping function
4.2.2.3.5	Loading with coherent transfer
4.2.2.3.6	Combined unloading and loading with non-coherent transfer, with/without clamping function
4.2.2.3.7	Combined unloading and loading with coherent transfer
4.2.2.3.8	Preparation of a part
4.2.2.3.9	Emptying
4.2.2.3.10	Function of guard doors
4.2.2.3.11	Further status functions
4.2.2.4	Conformance class 3: Extended set of signals with process optimization
4.2.2.4.1	General
4.2.2.4.2	Process optimizations at combined unloading and loading
4.2.2.4.2.1	General
4.2.2.4.2.2	With coherent transfer
4.2.2.4.2.3	With non-coherent transfer, with/without clamping function
4.2.2.4.3	Process optimizations, if pre-positioning by machine
4.2.2.4.4	Process optimizations, if clamping and releasing is executed in more than one step
4.2.3	Conformance options
4.2.3.1	General
4.2.3.2	Conformance option: Loading access controlled by machine
4.2.3.3	Conformance option: Loading access controlled by automated machine tending system
4.2.3.4	Conformance option: Enabling device
4.2.3.5	Conformance option: Monitoring of communication
4.2.3.6	Conformance option: Tool life management
4.2.3.7	Conformance option: Central functions
4.2.3.8	Conformance option: Control signals for safety-relevant functions
4.2.3.9	Conformance option: With parts data

- 4.2.3.9.1 General
- 4.2.3.9.2 Signals for controlling data handling
- 4.2.3.9.3 Preparation data and parts data
  - 4.2.3.9.3.1 Signal names and content of preparation data and parts data
  - 4.2.3.9.3.2 Use of preparation data and parts data
- 4.2.3.10 Conformance option: Setup information
- 4.2.3.11 Conformance option: Machine panel
- 4.2.3.12 Conformance option: Part seat control
- 4.3 Safety interface
  - 4.3.1 General
  - 4.3.2 Principle approach and concept
  - 4.3.3 Matrix for safety-related functional relationships
  - 4.3.4 Distribution of performance levels and PFHD value
- 4.4 Control interface

## 5 Extension of the interfaces

- 5.1 General
- 5.2 Examples of project-specific extensions
  - 5.2.1 General
  - 5.2.2 Additional signals
  - 5.2.3 More than one interference area
    - 5.2.3.1 Separated safety areas
    - 5.2.3.2 The same safety area

## Annex A (normative) List of signals

## Annex B (informative) Examples for safety matrices

- B.1 General
- B.2 Example 1: System configuration with loading setup space without (closable) loading access
  - B.2.1 Configuration
  - B.2.2 Safety matrix
  - B.2.3 Explanation of the scenarios
    - B.2.3.1 Development of the matrix
    - B.2.3.2 Scenario 0
    - B.2.3.3 Scenario 1
    - B.2.3.4 Scenario 2
    - B.2.3.5 Scenario 3
    - B.2.3.6 Scenario 4
    - B.2.3.7 Scenario 5
    - B.2.3.8 Scenario 6
    - B.2.3.9 Scenario 7
    - B.2.3.10 Scenario 8
- B.3 Example 2: Loading setup space with loading access
  - B.3.1 Configuration
  - B.3.2 Safety matrix
  - B.3.3 Explanation of the scenarios
    - B.3.3.1 Development of the matrix
    - B.3.3.2 Scenario 0
    - B.3.3.3 Scenario 1
    - B.3.3.4 Scenario 2
    - B.3.3.5 Scenario 3
    - B.3.3.6 Scenario 4
    - B.3.3.7 Scenario 5
    - B.3.3.8 Scenario 6
    - B.3.3.9 Scenario 7
    - B.3.3.10 Scenario 8
    - B.3.3.11 Scenario 9
    - B.3.3.12 Scenario 10
- B.4 Example 3: Loading of workspace with loading access from above for several machines
  - B.4.1 Configuration
  - B.4.2 Safety matrix
  - B.4.3 Explanation of the scenarios

- B.4.3.1 Development of the matrix
- B.4.3.2 Scenario 0
- B.4.3.3 Scenario 1
- B.4.3.4 Scenario 2
- B.4.3.5 Scenario 3
- B.4.3.6 Scenario 4

**Annex C (normative) Flow charts**

- C.1 Conformance class 1
  - C.1.1 Simple unloading
  - C.1.2 Simple loading
  - C.1.3 Simple combined unloading and loading
- C.2 Conformance class 2
  - C.2.1 Unloading with non-coherent transfer, with/without clamping function
  - C.2.2 Unloading with coherent transfer
  - C.2.3 Loading with non-coherent transfer, with/without clamping function
  - C.2.4 Loading with coherent transfer
  - C.2.5 Combined unloading and loading with non-coherent transfer, with/without clamping function
  - C.2.6 Combined unloading and loading with coherent transfer
  - C.2.7 Emptying
  - C.2.8 Functions of guard doors
- C.3 Conformance class 3
  - C.3.1 Process optimizations at the combined unloading and loading with non-coherent transfer, with/without clamping function
  - C.3.2 Process optimizations at the combined unloading and loading with coherent transfer
- C.4 Conformance options
  - C.4.1 Monitoring of communication
  - C.4.2 Conformance option: With parts data
    - C.4.2.1 Loading with preparation data from the machine to the automated machine tending system
    - C.4.2.2 Unloading with preparation data from the machine to the automated machine tending system
    - C.4.2.3 Loading with preparation data from the automated machine tending system to the machine
    - C.4.2.4 Unloading with preparation data from the automated machine tending system to the machine
    - C.4.2.5 Unloading with parts data
    - C.4.2.6 Loading with parts data
    - C.4.2.7 Loading with part reference number
  - C.4.3 Conformance option: Part seat control

Page count: 44