

ISO 13381-1:2004-11 (E)

Condition monitoring and diagnostics of machines - Prognostics - Part 1: General guidelines

| Contents | | Page |
|---|---|-------------|
| Foreword | | iv |
| Introduction | | v |
| 1 | Scope | 1 |
| 2 | Normative references | 1 |
| 3 | Terms and definitions | 1 |
| 4 | Pre-requisite data required | 2 |
| 5 | Prognosis concepts | 3 |
| 5.1 | Basic concepts | 3 |
| 5.2 | Influence factors | 5 |
| 5.3 | Setting alert, alarm and trip (shut-down) limits | 6 |
| 5.4 | Multiple parameter analysis | 8 |
| 5.5 | Initiation criteria | 10 |
| 5.6 | Prognosis of failure mode initiation | 11 |
| 6 | Failure and deterioration models used for prognostics | 12 |
| 6.1 | Modelling concepts for failure mode behaviour | 12 |
| 6.2 | Modelling types | 13 |
| 7 | Generic prognosis process | 13 |
| 7.1 | Prognosis confidence levels | 13 |
| 7.2 | Prognosis process | 13 |
| 8 | Prognosis report | 15 |
| Annex A (normative) Condition monitoring flowchart | | 16 |
| Annex B (normative) Example of the determination of the confidence level of a prognosis | | 17 |
| Annex C (informative) Failure modelling techniques | | 18 |
| Bibliography | | 20 |